

# Auxiliary input (AUX IN) socket

## AUXILIARY INPUT (AUX IN) SOCKET

### WARNINGS



Make sure that any auxiliary devices are stored securely while the vehicle is in motion. Any loose objects can present a serious hazard during sudden manoeuvres, emergency braking or an accident.



Do not place any item connected to the auxiliary input socket or the auxiliary power socket on the vehicle's seats, carpets, or other upholstery. The heat generated by these devices may cause damage to the upholstery, or in extreme cases, a vehicle fire.



Do not leave any auxiliary input devices connected while the vehicle is left unattended. There is a risk of heat damage or fire, in addition to the risk of theft.


### CAUTION



Read the manufacturer's instructions for any device before it is connected to the vehicle's audio system. Keep to any instructions about connection and operation and make sure that the device is suitable. Failure to do so may result in damage to the vehicle's audio system or the auxiliary device.

**AUX** (Auxiliary Input) mode allows extra equipment to be connected to the vehicle's audio system. Items such as a personal stereo, MP3 player, hand-held navigation unit etc., can be plugged in to the vehicle's audio system.

**Note:** *The volume levels and sound quality available from devices connected to the auxiliary inputs may vary widely. If the connected audio device is equipped with a line out socket as well as a headphone socket, the line out socket should be used.*




The auxiliary connector is situated at the rear of the centre console.

1. The auxiliary power socket, situated next to the auxiliary input connector, can be used to power or charge any suitable device.
2. Auxiliary audio devices are connected via the 3.5 mm stereo jack socket.

# Auxiliary input (AUX IN) socket

---

## Auxiliary mode



E83265

To listen to an auxiliary input source, connect the device and press the **CD or AUX** button on premium audio units. The unit will playback audio via the 3.5 mm stereo jack socket.

Alternatively, repeatedly press the **MODE** button on the steering wheel or the rear audio controls until **AUX** is selected.