


Convenience features

CLOCK


The clock is set through the audio system.

Setting the clock







E82914

1. Switch on the audio system, by pressing the volume rotary control.



E82981

2. Press the **MENU** button to access the function menu.




E83267


3. Rotate the control to select **Clock** and press to confirm selection.
4. Use the rotary control to adjust the **Time Mode** (12 or 24 hr), press to confirm selection.
5. Use the rotary control to adjust the **hour** displayed, press to confirm selection.
6. Use the rotary control to adjust the **minutes** displayed, press to confirm selection.
7. Press the **EXIT** button to cancel and to return to the menu.

Convenience features

SUN VISORS




CIGAR LIGHTER



With the ignition on, and/or the engine running, press in the centre of the cigar lighter. When the cigar lighter element has reached the correct temperature it will partially eject and can be withdrawn for use.

After use push the lighter back into the first position.

ASHTRAY



WARNING




Do not use the ashtrays for disposing of waste paper, or other combustible items. The resulting fire may cause death or serious injury.

To empty the ashtrays fully open the lid, then pull the ashtray upwards to remove.

Convenience features

AUXILIARY POWER SOCKETS




LAN1681

CAUTIONS

- ⚠ Only Land Rover approved accessories should be plugged into the power sockets. Using any other equipment may damage the vehicle's electrical system. If you are in any doubt contact a Land Rover Dealer.
 - ⚠ The engine should be running when using accessories for long periods. Failure to do so can discharge the battery.
-

Convenience features

CUP HOLDERS



E82051

1. Bottle holders.
2. Cup holders.

WARNINGS



The cup and bottle holders should only be used for soft containers. Containers which are hard (cans, metal, ceramic, hard plastic etc.) can cause serious injury if the vehicle is involved in an accident, sudden manoeuvre or braking.






Do not carry open drinks containers. Hot liquids can cause serious injury when spilled and may damage the vehicle.



Do not drink, or use the drinks holders when driving. Doing so would break concentration, which may result in loss of control.

Convenience features

STORAGE COMPARTMENTS



E82050

1. Coin/trinket trays.
2. Map pockets.
3. Storage compartments.
4. Glove box.
5. Rear armrest storage compartment.


WARNING



Ensure that any items stored in the vehicle are secure and cannot move. If the vehicle is involved in an accident, or subject to sudden braking or direction change, loose items can cause serious injury.

Convenience features

Glovebox storage



1. Coin storage slots.
2. Literature pack.
3. CD cassette.
4. Mobile phone holder.
5. Pen holder.
6. Ticket holder.