
AUDIO UNIT OVERVIEW

Standard audio unit




E81803

1. Radio station pre-sets
2. Information display screen
3. Audio menu button:
   - Access
   - Save
   - Close
4. Audio menu button:
   - Back
   - Exit
5. Audio menu control
   - Rotate to scroll through options
   - Press to enable or disable the function
6. Automatic forward tuning/search button
   - Radio station automatic forward search
   - Compact disc forward search
7. Manual tuning/scan up button
   - Radio station manual forward search
   - Compact disc scan up
8. Compact disc slot
9. Compact disc eject button
10. Manual tuning/scan down button
    - Radio station manual rearward search
    - Compact disc scan down
11. Automatic rearward tuning/search button
    - Radio station automatic rearward search
    - Compact disc rearward search
12. On/off and volume control
    - Press to switch on/off
    - Rotate to change volume
13. Traffic information (TA) or News button
    - Short press for traffic announcements
    - Long press for News announcements
14. Tone and volume settings button
    - Short press for tone settings menu
    - Long press for volume settings menu
15. Auxiliary input mode button
16. Compact disc player mode button
17. AM waveband button
18. FM waveband button

Audio unit overview

Premium audio unit



1. Input keypad
   - Function (frequency, track number, telephone numbers, text etc.)
2. Information display screen
3. Telephone mode button
4. Audio menu button:
   - Access
   - Save
   - Close
5. Audio menu button:
   - Back
   - Exit
6. Audio menu control
   - Rotate to scroll through options
   - Press to enable or disable the function
7. Automatic forward tuning/search button
   - Radio station automatic forward search
   - Compact disc forward search
8. Manual tuning/scan up button
   - Radio station manual forward search
   - Compact disc scan up
9. Compact disc slot
10. Compact disc eject button
11. Manual tuning/scan down button
    - Radio station manual rearward search
    - Compact disc scan down
12. Automatic rearward tuning/search button
    - Radio station automatic rearward search
    - Compact disc rearward search
13. On/off and volume control
    - Press to switch on/off
    - Rotate to change volume
14. Traffic information (TA) or News button
    - Short press for traffic announcements
    - Long press for News announcements
15. Tone and volume settings button
    - Short press for tone settings menu
    - Long press for volume settings menu
16. Auxiliary input mode button
17. Compact disc player mode button
18. AM waveband button
19. FM waveband button