# Keys and remote controls

### PRINCIPLE OF OPERATION

#### CAUTION

Remove all Smart Keys from the vehicle when it is left unattended. This will ensure the vehicle is left in a secure condition.

If a Smart Key is lost, a replacement can be obtained and programmed to the vehicle by your Dealer. Notify your Dealer as soon as a Smart Key is lost or stolen and have the remaining Smart Key(s) reprogrammed.



The security system and entry to the vehicle are controlled by the Smart Key remote control. All doors and the luggage compartment can be locked and unlocked using the remote control buttons.

The Smart Key also allows the vehicle to be started without the use of a conventional starter key. See **KEYLESS STARTING** (page 130).

Two Smart Keys, incorporating an emergency key blade, are supplied. Separate emergency key blades are available from Dealers.

The emergency key blade number is recorded on an attached label. Peel off the label and attach it to the designated area on the Security Card, supplied in the literature pack. Keep the Security Card safe, but not in the vehicle.

## **Keyless Entry**

Keyless Entry is an enhancement of the Smart Key and allows entry to the vehicle, without the need to press a button. Full security integrity of the vehicle is still maintained. See **KEYLESS ENTRY** (page 23).

# GENERAL INFORMATION ON RADIO FREQUENCIES

**Note:** The radio frequency used by your Smart Key may be used by other devices. For example: amateur radios, medical equipment, wireless headphones, or other remote control devices. This may cause the frequency to be jammed, and prevent your remote control from operating correctly.

Environmental conditions can affect the operation of Smart Keys and the operating range may vary considerably depending on the vehicle's location.