

Engine immobiliser

PRINCIPLE OF OPERATION

CAUTION



The immobiliser may suffer interference from other legal users of this frequency band.

Engine immobilisation is an important aspect of the security system. It is designed to safeguard the vehicle from theft, should the driver forget to lock the doors. The system prevents the engine from being started unless a genuine Smart Key is detected within the vehicle.

Engine immobilisation occurs automatically five seconds after the Smart Key is removed from the vehicle.

Note: *The engine will be re-mobilised automatically whenever a recognised Smart Key is detected within the vehicle. When this happens, the anti-theft alarm indicator illuminates briefly.*

CODED KEYS

Note: *A replacement Smart Key can only be obtained from your Land Rover Dealer/ Authorised Repairer. The Dealer will require proof of ownership.*

Notify your Dealer immediately if a Smart Key is lost or stolen.