
Digital Audio Broadcasting (DAB)

AUDIO CONTROLS



1. Settings
2. Audio on/off
3. Volume
4. Access Audio/Video Menu
5. Seek up.
   - Short press to find the next channel.
   - Long press (two seconds) to find next available ensemble.
6. Seek down.
   - Short press to find previous channel.
   - Long press (two seconds) to find previous available ensemble.