


Starting the engine

KEYLESS START BACKUP

If the vehicle has been unlocked using the emergency key blade or the Smart Key is not detected by the vehicle, it will be necessary to use the keyless start backup to disarm the alarm and start the engine.

The keyless start backup can only be used when the message **Smart Key Not Found Place As Shown** is displayed in the message centre.



LAN2243

Position the Smart Key against the underside of the steering column cover with the buttons facing downwards.

Note: *There are markings on the cover to help locate the correct position.*

When the Smart Key is positioned in this area it will be recognised by the vehicle and the message **Smart Key Recognised** will be displayed in the message centre.

Holding the Smart Key in position and the brake or clutch pedal depressed, press and release the START/STOP button to start the engine.

Once the engine has been started you no longer need to hold the Smart Key against the steering column cover.

Note: *If the Smart Key is not recognised, or the engine still fails to start, consult your Dealer/ Authorised Repairer*

STOPPING THE ENGINE

WARNING



Never switch off the engine when the vehicle is in motion.

Before stopping the engine, ensure that the vehicle is parked safely with the park brake applied. On automatic transmission vehicles the gear selector will also need to be in Park **P**.

Press and release the engine START/STOP button to stop the engine. The audio, telephone and touch screen systems will revert to stand-by mode.

Pressing the START/STOP button again (without pressing the brake or clutch pedal) will activate the systems.