

Digital Audio Broadcasting (DAB)

USING DAB


To receive digital broadcasts, briefly touch the **DAB Radio** button on the touch-screen.

Choose **DAB1**, **DAB2** or **DAB3** to receive digital radio broadcasts. The three DAB sources enable you to preset up to 18 different channels.

The channel that was last played on your chosen digital source will be selected for playback automatically.

Note: *If this is the first time you have used DAB radio, you will be unable to listen to any digital broadcasts until you have searched for a list of available channels using the auto-tune function.*

CHANNEL AUTOMATIC TUNING



LAN2041

In DAB mode, select **DAB search**, then select **Auto-tune** to start automatic tuning and build a list of all the digital ensembles and channels that are available in your region.

While automatic tuning is running, the message **Auto-tuning** will be displayed on the touch-screen, along with a percentage complete. When tuning is complete, the first channel found will start playing.

Note: *The auto-tune process can take longer than one minute to complete.*

To update the list of local channels when you move to a different region, select **Auto-tune** again. You can also add local channels as presets to minimise the need for auto-tuning as you move location.

Note: *Store the channels you listen to frequently as presets. This will prevent them being lost when you use the auto-tune process.*