



Lighting

FRONT FOG LAMPS




LAN2206

With either the side lamps or low beam headlamps switched on, press the button to switch on the front fog lamps.

 A green warning indicator will illuminate in the instrument pack when the front fog lamps are switched on.


Press the button again to switch off the fog lamps.

REAR FOG LAMPS



LAN2207

With either the front fog lamps or low beam headlamps switched on, press the button to switch on the rear fog lamps.

 An amber warning indicator will illuminate in the instrument pack when the rear fog lamps are switched on.

Press the button again to switch off the fog lamps.

HAZARD WARNING FLASHERS



LAN2200

Press the switch to operate the hazard warning lamps. All of the direction indicator lamps will flash together.

Use only in an emergency to warn other road users when the stationary vehicle is causing an obstruction, or is in a hazardous situation. Remember to switch off before moving away.