

Keys and remote controls

LOCKING AND ARMING THE VEHICLE

WARNING



The vehicle will only lock, if all door, tailgate and bonnet apertures are closed. If a lock attempt is made when an aperture is open, the vehicle will not lock and two audible error warnings will sound.



Press the lock button to secure the vehicle. The vehicle can be Single or Double locked, as follows:

Single locking

Press the lock button briefly. Single locking secures the vehicle and prevents the doors being opened from outside of the vehicle. The doors can be unlocked and opened from inside the vehicle. The hazard warning lamps will flash once as confirmation.

Note: In some markets, an audible warning will sound.

Double locking

WARNING



Never double lock the vehicle with people, children, or pets inside. In the event of an emergency they would be unable to escape, and the emergency services would be unable to release them quickly.

Press the lock button twice within three seconds. Double locking secures the vehicle and prevents the doors being unlocked or opened from inside or outside of the vehicle, except with a recognised Smart Key. The hazard warning lamps will flash twice (with a long second flash) and an audible warning will sound, as confirmation.

Double locking provides additional security if the vehicle is left unattended. The vehicle cannot be opened by breaking a window and operating the door locks from inside the vehicle.

Mislock warning

If one of the doors, the tailgate, or the bonnet are not shut fully when the vehicle is locked using the Smart Key, the vehicle will not lock and two warning tones will sound. Check that all doors, the bonnet and the luggage compartment are closed properly and lock the vehicle again.

Lock confirmation

If you are uncertain whether the vehicle is locked and armed (either by single or double locking), press the lock button again. The hazard warning lights will flash to indicate and confirm the current lock status.

Note: If the vehicle is not already locked and armed, pressing the lock button will single lock the vehicle. Press again to double lock, if required.

Automatic relocking

If a door, or the tailgate, are not opened within one minute of unlocking the vehicle using the Smart Key, the vehicle will relock and the alarm will re-arm.