

# Supplementary restraints system

## Airbag switched ON

### WARNING



To ensure that the adult restraint system performs as intended, make sure that the passenger airbag is switched ON.



E82246

When an adult is seated in the front passenger seat of your vehicle, ensure that the passenger airbag disabling switch is turned to the **ON** position.

This will ensure that the airbag will perform as intended in the event of a crash.

Check that when the ignition is switched on, the operational status lamp on the fascia is not illuminated, confirming that the passenger airbag is operational.

## AIRBAG WARNING LAMP

### WARNING



If the warning indicator signals that a fault is present in the system, do not use a child restraint on the front passenger seat. Doing so will increase the risk of death or serious injury to the child.



A red warning indicator in the instrument pack will alert you to any malfunction of the airbag SRS. On vehicles with a message centre, this will be accompanied by the message **AIRBAG FAULT**. Seek qualified assistance urgently if any of the following symptoms occurs:

- The warning indicator fails to illuminate when the ignition is switched on.
- The warning indicator fails to extinguish within approximately four seconds after the ignition is switched on.
- The warning indicator illuminates after the engine is started, or while the vehicle is being driven.