BLUETOOTH SETUP

If your mobile phone supports this wireless feature, it will need to be bonded to the vehicle. The bonding process will also be described in your mobile phone instructions.


1. With the vehicle ignition on, select the Bluetooth feature on your mobile phone.
2. Start the Search function on your mobile phone. This search process may vary from one handset/manufacturer to another (consult your mobile phone instructions for further details). Typically, when searching for other wireless devices the search range is 10 metres or less.
3. The text **LAND ROVER** will appear on your mobile phone device list. This should be selected. **LAND ROVER** can be personalised by the user (e.g. the vehicle registration number).
4. The screen will display a PIN depending on the model of phone being bonded. Enter the PIN displayed.
5. When the PIN is accepted, the system will allow you to use the Bluetooth mode.

Note: *A maximum of five mobile phones can be bonded to the vehicle.*

Note: *If more than one paired Bluetooth phone is in range, then the system will automatically select the last phone used in Bluetooth mode (if present). If the last connected phone is not present the system will move through previously connected phones until a bonded phone is discovered.*

Note: *The searching/bonding process may take some time to complete, especially if more than one phone is bonded to the system.*

Note: *Priority can be given to other phones by de-selecting Bluetooth mode on your mobile phone.*



LAN2589

If Bluetooth bonding is attempted when there are no free slots available, a pop up message will appear stating that there are none available. Press **OK** to confirm and to return to the **Select phone to Debond** screen.

Selecting **Debond** opens the **Select phone to Debond** screen. Right navigation on the selected phone opens the **Select phone to Debond** screen. Selecting No returns to the **Select phone to Debond** screen. Selecting yes debonds the phone and then returns to the **Select phone to Debond** screen. Left navigation cancels back to the previous screen displayed.

Note: *The debond option is not available if no phones are bonded.*