


# Digital Audio Broadcasting (DAB)

## DISPLAY OPTIONS

### Touch-screen information panel




LAN2038

1. DAB band indicator.
2. **TA-FM** is displayed if the FM traffic option is enabled.
3. **DAB-i** indicates that DAB Announcements are enabled.
4. Channel name.
5. The arrow icon indicates that subchannels are available under the current channel. **SubCh** is displayed if a subchannel is tuned to.
6. **Link** is displayed if the Link DAB option is enabled.
7. Signal strength indicator.

**Note:** The display can also show **PTY** or **Ensemble** information if you have selected one of these options under **DAB text** on the **Settings** menu.

## DAB radio text

Many digital channels transmit additional text (DLS, Dynamic Label Segment) to accompany a broadcast. For safety reasons, this text does not scroll across the screen.



LAN2039

The first 16 characters of text are displayed (1). If you want to read the full text, you must select the additional text icon (2).



LAN2040

The **DAB radio text** pop-up screen displays all 128 characters of text. This text may change periodically, if the broadcaster chooses to do so.

To remove the pop-up screen, briefly touch it.