



DISCOVERY 4

OWNER'S HANDBOOK

Publication Part No. LRL 10 02 53 101

This handbook forms part of the Owner literature supplied with your new vehicle. Left hand drive and right hand drive conditions may be shown in the graphics and where information is specific to a particular country, it is indicated as such.

Please take the time to study the operating instructions with your vehicle as soon as you can.

Important

The information contained in this handbook covers all vehicle derivatives and optional equipment. Some of the options may not be fitted to your vehicle unless they formed part of the original vehicle specification. Therefore some parts of this handbook may not apply to your vehicle. Furthermore, due to printing cycles, it may include descriptions of options before they become generally available.

The options, hardware and software in your vehicle are from the available specifications for the market in which the vehicle was intended for sale. If your vehicle is to be used in another geographical area you may have to modify the vehicle specification to suit local conditions. Land Rover is not responsible for the cost of any modifications.

The information contained in this publication was correct when it went to print. Vehicle design changes may have been made after this handbook was printed. When this occurs a handbook supplement is added to the literature pack. Subsequent updates can be viewed on the Land Rover Internet site at; **www.ownerinfo.landrover.com**.

In the interest of development, the right is reserved to change specifications, design or equipment at any time without notice and without incurring any obligations. This publication, or part thereof, may not be reproduced nor translated without our approval. Errors and omissions excepted.

© Land Rover 2009

All rights reserved.

Published by Land Rover Technical Communications.

Contents

Introduction

SYMBOLS GLOSSARY	8
LABEL LOCATIONS	8
HEALTH AND SAFETY	9
DATA RECORDING	10
DISABILITY MODIFICATIONS	11
PARTS AND ACCESSORIES	11

Keys and remote controls

PRINCIPLE OF OPERATION	13
GENERAL INFORMATION ON RADIO FREQUENCIES	13
USING THE SMART KEY	14
UNLOCKING AND DISARMING THE VEHICLE	15
LOCKING AND ARMING THE VEHICLE	16
CHANGING THE SMART KEY BATTERY	17
EMERGENCY KEY BLADE	17
GLOBAL OPENING AND CLOSING OF WINDOWS	18

Locks

LOCKING AND UNLOCKING	19
VALET MODE	20
USING THE EMERGENCY KEY BLADE	21
SMART KEY SYSTEM TRANSMITTERS	22
KEYLESS ENTRY	23
KEYLESS LOCKING	24
STEERING COLUMN LOCK	24

Engine immobiliser

PRINCIPLE OF OPERATION	25
CODED KEYS	25

Alarm

PRINCIPLE OF OPERATION	26
ARMING THE ALARM	26
SWITCHING OFF THE ALARM	27
TILT SENSOR	27

Facia

FACIA OVERVIEW	28
----------------------	----

Driver information module

INFORMATION MESSAGES	30
TRIP COMPUTER	31
SERVICE INTERVAL INDICATOR	32
GEAR SELECTOR DISPLAY	32
VEHICLE INFORMATION AND SETTINGS MENU	33

Instruments

INSTRUMENT PANEL OVERVIEW	36
GAUGES	37
WARNING INDICATORS	38

Seats

SITTING IN THE CORRECT POSITION	40
MANUAL SEATS	41
ELECTRIC SEATS	42
DRIVER'S SEAT MEMORY FUNCTION	44
HEAD RESTRAINTS	45
REAR SEATS	46
HEATED SEATS	52

Seat belts

GENERAL INFORMATION	53
SEAT BELT REMINDER	55
FASTENING THE SEAT BELTS	56
SEAT BELT HEIGHT ADJUSTMENT	56
USING SEAT BELTS DURING PREGNANCY	57

Supplementary restraints system

PRINCIPLE OF OPERATION	58
SIDE AIRBAGS	61
CURTAIN AIRBAGS	61
DISABLING THE PASSENGER AIRBAG	62
AIRBAG WARNING LAMP	64
AIRBAG SERVICE INFORMATION	65

Child safety

CHILD SEATS	66
CHILD SEAT POSITIONING	68
ISOFIX ANCHOR POINTS	70
BOOSTER CUSHIONS	72
CHILD SAFETY LOCKS	72

Contents

Steering wheel

ADJUSTING THE STEERING COLUMN	73
HEATED STEERING WHEEL.....	74
AUDIO CONTROL	75
VOICE CONTROL	75
CRUISE CONTROL.....	75
HORN	75

Lighting

GENERAL INFORMATION	76
LIGHTING CONTROL	77
FRONT FOG LAMPS.....	79
REAR FOG LAMPS.....	79
HAZARD WARNING FLASHERS.....	79
HEADLAMPS - DRIVING ABROAD.....	80
ADAPTIVE FRONT LIGHTING SYSTEM	80
DIRECTION INDICATORS	82
INTERIOR LAMPS	82
REMOVING A HEADLAMP	83
REMOVING A REAR LAMP	85
CHANGING A BULB	85
HEADLAMP UNIT BULBS	86
FRONT FOG LAMP BULB.....	90
SIDE REPEATER LAMP BULB.....	91
REAR LAMP BULBS	92
INTERIOR LAMP BULBS	93
BULB SPECIFICATION CHART	94

Wipers and washers

WINDSCREEN WIPERS	95
RAIN SENSOR	96
WINDSCREEN WASHERS.....	97
REAR WINDOW WIPER AND WASHERS.....	97
HEADLAMP POWER WASH.....	98
ADJUSTING THE WINDSCREEN WASHER JETS	98
CHECKING THE WIPER BLADES	99
CHANGING THE WIPER BLADES.....	99

Windows and mirrors

ELECTRIC WINDOWS.....	101
EXTERIOR MIRRORS	102
INTERIOR MIRROR	104

Climate control

AIR VENTS	105
AUTOMATIC CLIMATE CONTROL	107
HEATED SCREENS AND MIRRORS.....	110
REAR PASSENGER CLIMATE CONTROLS.....	111
AUXILIARY HEATER.....	111
TIMED CLIMATE CONTROL	112
ELECTRIC SUNROOF.....	115

Convenience features

SUN VISORS	117
SUN BLINDS	117
INSTRUMENT LIGHTING DIMMER	117
CIGAR LIGHTER	118
ASHTRAY	118
AUXILIARY POWER SOCKETS	119
CUP HOLDERS.....	120
CENTRE CONSOLE.....	121
COOL BOX.....	122
STORAGE COMPARTMENTS.....	123

Homelink

HOMELINK® TRANSMITTER	124
-----------------------------	-----

Starting the engine

GENERAL INFORMATION.....	129
SWITCHING ON THE IGNITION	129
KEYLESS STARTING	130
IF THE ENGINE FAILS TO START	130
KEYLESS START BACKUP	131
STOPPING THE ENGINE.....	131

Transmission

MANUAL TRANSMISSION	132
AUTOMATIC TRANSMISSION.....	132
CommandShift™ GEAR SELECTION.....	134
ELECTRONICALLY SELECTED AUTOMATIC MODES.....	135
TRANSFER GEARBOX	137

Brakes

PRINCIPLE OF OPERATION	140
HINTS ON DRIVING WITH ABS.....	142
ELECTRIC PARKING BRAKE (EPB)	143

Contents

Camera systems

REAR VIEW CAMERA SYSTEM.....	147
SURROUND CAMERA SYSTEM.....	148

Parking aid

PRINCIPLE OF OPERATION.....	152
USING THE PARKING AID.....	152

Driving hints

GENERAL DRIVING POINTS.....	154
RUNNING-IN.....	155
ENGINE RELATED PROBLEMS.....	156
ECONOMICAL DRIVING.....	156
DIESEL PARTICULATE FILTER (DPF).....	157

Cruise control

PRINCIPLE OF OPERATION.....	158
USING CRUISE CONTROL.....	158

Stability control

PRINCIPLE OF OPERATION.....	160
USING STABILITY CONTROL.....	160
ROLL STABILITY CONTROL (RSC).....	161
TRAILER STABILITY ASSIST (TSA).....	161

Traction control

PRINCIPLE OF OPERATION.....	162
SAND LAUNCH CONTROL.....	162
ROCK CRAWL PRECHARGE.....	162

Hill descent control (HDC)

PRINCIPLE OF OPERATION.....	163
USING HDC.....	163

Terrain response

PRINCIPLE OF OPERATION.....	166
USING TERRAIN RESPONSE.....	166

Air suspension

PRINCIPLE OF OPERATION.....	171
ADJUSTING THE SUSPENSION.....	172
REMOTE OPERATION.....	178

Fuel and refuelling

SAFETY PRECAUTIONS.....	179
FUEL SPECIFICATION.....	179
FUEL FOR PETROL ENGINES.....	180
ALTERNATIVE FUELS FOR PETROL ENGINES.....	180
FUEL FOR DIESEL ENGINES.....	181
FUEL FILLER.....	182
REFUELLING.....	183
DIESEL MISFUEL PROTECTOR.....	183
RUNNING OUT OF FUEL.....	184
DIESEL WATER IN FUEL SENSOR.....	185
FUEL CUT-OFF.....	185
CATALYTIC CONVERTER.....	185
FUEL CONSUMPTION.....	186

Load carrying

GENERAL INFORMATION.....	187
LUGGAGE ANCHOR POINTS.....	187
REAR LOADSPACE HATCHES.....	187
LUGGAGE COVERS.....	188

Towing

TOWING A TRAILER.....	190
LEVELLING.....	194
ESSENTIAL TOWING CHECKS.....	195
GEAR CHANGING.....	195
RECOMMENDED TOWING WEIGHTS.....	196
DETACHABLE TOW BALL.....	197
TOW BALL STOWAGE.....	199

Vehicle care

CLEANING THE EXTERIOR.....	200
CLEANING THE ALLOY WHEELS.....	201
CLEANING THE INTERIOR.....	201
REPAIRING MINOR PAINT DAMAGE.....	203

Maintenance

GENERAL INFORMATION.....	204
SAFETY IN THE GARAGE.....	205
OPENING AND CLOSING THE BONNET.....	206
ENGINE COMPARTMENT OVERVIEW.....	207
UNDER BONNET COVERS.....	209
ENGINE OIL.....	209
ENGINE OIL CHECK (2.7L DIESEL AND V6 PETROL).....	210
ENGINE OIL CHECK (3.0L DIESEL).....	211

Contents

ENGINE OIL CHECK (V8 PETROL)	213
ENGINE COOLANT CHECK	215
BRAKE FLUID CHECK	216
POWER STEERING FLUID CHECK	218
WASHER FLUID CHECK	219
TECHNICAL SPECIFICATIONS	220

Vehicle battery

BATTERY WARNING SYMBOLS	222
BATTERY CARE	222
USING BOOSTER CABLES	223
CHARGING THE VEHICLE BATTERY	225
CHANGING THE VEHICLE BATTERY	226
REFITTING THE VEHICLE BATTERY	227

Wheels and tyres

GENERAL INFORMATION	228
TOOL KIT	229
CHANGING A ROAD WHEEL	230
TYRE CARE	243
USING WINTER TYRES	248
APPROVED WINTER TYRES	249
USING SNOW CHAINS	249
TYRE PRESSURE MONITORING SYSTEM	250
TYRE GLOSSARY	254
TECHNICAL SPECIFICATIONS	255

Fuses

FUSE BOX LOCATIONS	256
CHANGING A FUSE	257
FUSE SPECIFICATION CHART	258

Status after a collision

DRIVING AFTER A COLLISION	263
INSPECTING SAFETY SYSTEM COMPONENTS	264

Vehicle recovery

TOWING POINTS	265
LASHING POINTS	267
TRANSPORTING THE VEHICLE	267
TOWING THE VEHICLE ON FOUR WHEELS ..	268

Vehicle identification

VEHICLE IDENTIFICATION NUMBER (VIN) ...	269
VEHICLE IDENTIFICATION PLATE	269
VEHICLE BUILD DATE PLATE	269
ENGINE NUMBER	269

Technical specifications

TECHNICAL SPECIFICATIONS	270
--------------------------------	-----

Type approvals

TYPE APPROVALS	276
----------------------	-----

Audio system overview

STANDARD AUDIO SYSTEM	286
TOUCH SCREEN AUDIO SYSTEM	287
TOUCH SCREEN CARE	288
SWITCHING THE SYSTEM ON	288
TURNING OFF THE TOUCH SCREEN	288

Audio system settings (touch screen)

PERSONALISING THE SYSTEM SETTINGS ...	289
SYSTEM SETTINGS	289
SCREEN SETTINGS	290
VEHICLE SETTINGS	291
VOICE SETTINGS	292

Audio level settings (touch screen)

VOLUME ADJUSTMENT	293
TONE ADJUSTMENT	294

Radio (standard)

RADIO RECEPTION	295
RADIO CONTROLS	296
VOLUME ADJUSTMENT	297
TONE ADJUSTMENT	297
RADIO OPERATION	297
RADIO DATA SYSTEM (RDS)	299
TRAFFIC INFORMATION	299
NEWS INFORMATION	300
TIME AND DATE SETTINGS	301

Contents

Radio (touch screen)

RADIO RECEPTION	302
RADIO CONTROLS.....	303
RADIO OPERATION	304
RADIO DATA SYSTEM (RDS)	305
TRAFFIC INFORMATION	306
NEWS INFORMATION	307
PRIORITY PROGRAMME TYPE (PTY)	307

Digital Audio Broadcasting (DAB)

GENERAL INFORMATION	308
AUDIO CONTROLS.....	310
USING DAB.....	311
CHANNEL AUTOMATIC TUNING	311
DISPLAY OPTIONS	312
PRESET CHANNELS.....	313
CHANNEL OPTIONS.....	314
SETTINGS	316

Compact disc player (standard)

COMPACT DISC COMPATIBILITY	319
PLAYING A COMPACT DISC	320
TRACK SELECTION	320
MP3 FILE PLAYBACK.....	321

Compact disc player (touch screen)

COMPACT DISC COMPATIBILITY	322
LOADING COMPACT DISCS.....	323
TRACK SELECTION	324
COMPACT DISC PAUSE.....	324
COMPACT DISC PLAY OPTIONS	325

Rear passenger controls

REAR SEAT CONTROLS.....	326
HEADPHONES.....	327

Portable audio interface

PORTABLE AUDIO INTERFACE	328
OPERATING A PORTABLE DEVICE	330
SEARCHING A PORTABLE DEVICE	331

Auxiliary input (AUX IN) socket

AUXILIARY INPUT (AUX IN) SOCKET	332
---------------------------------------	-----

Voice control

USING VOICE CONTROL	334
DISPLAY COMMANDS	336
NOTEPAD COMMANDS	336

Telephone (standard)

GENERAL INFORMATION	337
MOBILE PHONE COMPATIBILITY.....	338
TELEPHONE CONTROLS	338
BLUETOOTH SETUP	339
SELECTING PHONE MODE	340
DIALLING	340
ANSWERING/REJECTING CALLS	340

Telephone (touch screen)

GENERAL INFORMATION	341
TELEPHONE CONTROLS	343
PHONE INFORMATION DISPLAY.....	344
BLUETOOTH SETUP	345
SELECTING PHONE MODE	346
DIALLING	346
ANSWERING/REJECTING CALLS	346
PHONEBOOK	347
SCRATCHPAD	348
CALL REGISTER	349
TELEPHONE VOICE CONTROL.....	350
DIALLING A PHONE NUMBER USING VOICE RECOGNITION	351
STORING A TELEPHONE NAME/ NUMBER WITH VOICE RECOGNITION	352
USING THE VOICE RECOGNITION PHONE DIRECTORY	353

Filling station information

FUEL FILLER FLAP	355
REFUELLING	355
TYRE PRESSURES	356
ENGINE OIL SPECIFICATION	356
ENGINE COOLANT SPECIFICATION.....	356