

# Wipers and washers

## WINDSCREEN WASHERS

### WARNING



In temperatures below 41°F (5°C), use a washer fluid with antifreeze protection. In cold weather, failure to use washer fluid with antifreeze protection could result in impaired vision and increase the risk of an accident.



Some screen wash products are flammable: do not allow screen wash to come into contact with sources of ignition.

### CAUTION



Only screen wash products which are approved for automotive use should be used and then only in accordance with the manufacturer's instructions.




E91450

A momentary press of the button will briefly operate the windscreen washer. A prolonged press will operate both the windscreen washer and the front wipers. When the button is released, the wipers will complete two further strokes before parking automatically.

**Note:** National or local regulations may restrict the use of Volatile Organic Compounds (VOCs), which are commonly used as antifreeze agents in washer fluid. A washer fluid with limited VOC content should be used only if it provides adequate freeze resistance for all climates in which the vehicle will be operated.

## REAR WINDOW WIPER AND WASHERS



E91451

### Wiper - intermittent operation

Pull the lever to position 1. The intermittent delay period will vary according to vehicle speed.

### Wiper - continuous operation

The rear wiper can be configured to operate continuously.



This setting can be configured by a Land Rover Dealer/Authorised Repairer.

### Washer

Pull the lever to position 2 and hold it. The wiper and washer will operate until the lever is released. When the lever is released, the washer will stop and the wiper will complete a further two wipe cycles and then return to intermittent operation.