



# Telephone (touch screen)

## Steering wheel



LAN2341





### 1. Answer call/Dial switch

- Press the switch briefly to answer an incoming call or dial a displayed number. Press and hold the switch (for approximately two seconds) to redial the last number dialed.

### 2. End/Reject call switch

- Press the switch to end the current call or reject an incoming call.

## PHONE INFORMATION DISPLAY



LAN2009

1. Active call icon.
2. Network or Bluetooth.
3. Scratchpad line (Max. 17 characters).
4. Call state icon.
5. Missed call icon.

**Note:** The phone operator logo and signal strength indicators will also be displayed, if supported by the mobile phone.