
Telephone (touch screen)


Steering wheel



LAN2341

1. Answer call/Dial switch
   - Press the switch briefly to answer an incoming call or dial a displayed number. Press and hold the switch (for approximately two seconds) to redial the last number dialled.
2. End/Reject call switch
   - Press the switch to end the current call or reject an incoming call.

PHONE INFORMATION DISPLAY



LAN2009

1. Active call icon.
2. Network or Bluetooth.
3. Scratchpad line (Max. 17 characters).
4. Call state icon.
5. Missed call icon.

Note: *The phone operator logo and signal strength indicators will also be displayed, if supported by the mobile phone.*