

# Alarm

---

## SWITCHING OFF THE ALARM

If the alarm is triggered, the siren will sound and the hazard warning lamps flash.

**Note:** *When the event that triggered the alarm is no longer present, the alarm system will return to the same protection status that existed before.*

To silence the alarm, press the unlock button on the Smart Key then press the lock button to either single or double lock the vehicle and reset the alarm.

## TILT SENSOR

Your vehicle may be fitted with a tilt sensor which activates the alarm if the vehicle is tilted fore and aft, or side to side, after it has been double locked.

The alarm will sound if theft is attempted by hoisting onto another vehicle or if a side is lifted to attempt wheel removal.

If required (e.g. when aboard a ferry or having the vehicle transported on a recovery truck), you can temporarily disable the vehicle's tilt sensor the next time the vehicle is locked with Smart Key, via the **Vehicle Set-up** menu. See

**VEHICLE INFORMATION AND SETTINGS MENU** (page 33).

**Note:** *This setting is automatically enabled the next time the vehicle is unlocked with the Smart Key.*