


# Convenience features


## SUN VISORS



EB0434

The sun visor can be pivoted downwards, or to the side as required to reduce glare.

## SUN BLINDS




EB0433

Pull the sunroof blind, across the sunroof aperture, until it locks in place.

To open, push vertically on the textured part of the blind handle. The blind will retract into the panel between the sunroofs.

## INSTRUMENT LIGHTING DIMMER



LAN2187

Rotate the dimmer control to vary the level of instrument pack illumination.