ENGINE RELATED PROBLEMS

Restricted performance

If the message RESTRICTED PERFORMANCE with a warning icon appears in the message centre an engine management fault has been registered.

If the warning icon is RED, reduced engine performance will be experienced. Stop the vehicle as soon as safety permits and seek qualified assistance.

If the warning icon is AMBER, reduced engine performance may be experienced. Consult a Land Rover Dealer/Authorised Repairer at the earliest opportunity.

Engine systems fault

If the message **ENGINE SYSTEMS FAULT** appears in the message centre, a serious engine problem has been detected. Stop the vehicle as soon as safety permits and seek qualified assistance. Continuing to drive the vehicle may cause serious damage to the engine.

Check engine



This warning indicator illuminates when the ignition is on and extinguishes as soon as the engine is started. Illumination at any other time indicates an engine fault - if the indicator illuminates or flashes while driving, avoid high speeds and seek qualified assistance as soon as possible.

ECONOMICAL DRIVING

There are two main factors which influence fuel economy, the way the vehicle is driven, and maintenance.

Driving tips for economy

- Avoid unnecessary journeys, especially short start-stop trips.
- Accelerate gently and smoothly from a stand still.
- Use the gears to avoid labouring, or over-revving the engine.
- Allow time to brake gently and smoothly.
- Be aware of traffic and road conditions ahead, and take action in time to avoid hard braking and acceleration.
- When stationary apply the park brake and select neutral.
- Turn off the air conditioning when not needed.

Maintenance and fuel economy

Regular servicing by your Dealer/Authorised Repairer, along with regular checking by the driver is essential for vehicle longevity and fuel economy. The condition of the engine (oils, filters, spark plugs, settings etc.) tyre pressures and wheel alignment will all have a bearing on fuel economy. For this reason it is essential that the vehicle is checked regularly by the driver and serviced at the correct intervals by an approved Dealer/Authorised Repairer.

Note: *If you are in any doubt about the maintenance requirements, intervals or checks required, contact your Dealer/Authorised Repairer for advice.*