SURROUND CAMERA SYSTEM



WARNING: It remains the driver's responsibility to detect obstacles and estimate the vehicle's distance from them when reversing.

The camera home page is accessed by touching **Camera** on the Home menu screen.

With the engine running and Park or Neutral selected, the surround camera system uses 5 discretely placed cameras to assist in maneuvering the vehicle.

SELECTING VIEWS

Displayed on the Camera home page is a real-time image from each of the cameras. Any 2 images can be selected and enlarged to view side-by-side on the screen. To do this, touch the image then touch the **Enlarge** soft key.

When viewing two images, one of them can be selected to view as a full screen image. It can then be zoomed into and panned around using the magnifier and arrow icons.

PROXIMITY VIEW

Selecting **Proximity View** will display a combination of three images from the front and passenger side cameras.

SPECIAL VIEWS

A selection of pre-set views can be displayed by selecting **Special Views**. They are provided to assist with difficult maneuvers and are:

- Curb view: Shows views from the 2 front cameras
- Junction view: Shows views from the two side cameras.
- Trailer view: Shows the rear camera view.

REVERSING

When Reverse is selected, the touch screen automatically displays the view to the rear of the vehicle.

Overlaid on the rear view image are colored dashed lines representing the perimeter of the vehicle, solid lines predicting the path of the vehicle (based on the position of the steering wheel) and the distance information from the Parking aid system.

Note: The overlaid reversing guidelines are fixed and do not respond to steering input.

Note: Touch the return icon in the bottom right hand corner of the reversing view, to go back to the previously viewed screen.

CAMERA CLEANLINESS

If the color of the camera position arrow in the display changes from blue to red, the system has detected that the camera is dirty. Clean the camera in accordance with the guidelines given on 179, CLEANING THE EXTERIOR.

TRAILER GUIDANCE

Note: Trailer guidance requires a connected trailer to be fitted with a tracking target sticker, which **must** be attached according to specific instructions. Ask your Land Rover Retailer/Authorized Repairer for details.



SL1315

Note: This feature may not operate with all trailer designs.

Trailer guidance aids trailer reversing, by displaying information on the touch screen.

Trailer guidance becomes active when a trailer is attached to the vehicle and the trailer electrical plug is attached to the vehicle socket. The screen will display a choice for connection. Select **YES** to move to the setup screen. Select **NO** to return to the previous screen.

Note: If the connection is not detected, setup can be manually prompted by touching the Trailer guidance icon on the Camera menu.

TRAILER SETUP

On first use, the setup screens take the user through a series of configuration options for the connected trailer. Information such as trailer length, number of axles and camera preference is required to finalize setup.

Once completed, the details are stored for future use.

OPERATION

When a new or existing trailer configuration is selected, Trailer guidance will automatically display on the touch screen when reverse gear is selected.

Colored lines are displayed to indicate the predicted path of both trailer and vehicle.