

CONTROLS

1. Map reading lamp switch.
2. Main interior lamp switch.
3. Passenger airbag warning lamp.
4. Sunroof switches.
5. Trip computer switch.
6. High beam/Direction indicator.
7. Cruise control switches.
8. Instrument pack and message centre.
9. Audio controls.
10. Wiper/washer controls.
11. START/STOP button.
12. Audio system and controls.
13. Display screen.
14. Parking aid switch.
15. Central locking, unlock.
16. Hazard warning light control switch.
17. Central locking, lock.
18. Stop/start system off button.
19. Main climate control panel.
20. Air conditioning on/off button.
21. Dynamic stability control on/off button.
22. Terrain response control.
23. Power socket.
24. Handbrake lever.
25. Gear selector.
26. Hill descent control (HDC) switch.
27. Climate control recirculation on/off switch.
28. Remote control docking port.
29. Telephone controls.
30. Horn buttons.
31. Steering column adjustment lever.
32. Exterior mirror adjustment controls.
33. Window switches.
34. Window isolator switch.
35. Headlamp levelling control.
36. Rear fog lamp switch.
37. Main exterior lighting control.
38. Front fog lamp switch.
39. Instrument illumination dimmer control.

