ABOUT THIS HANDBOOK

Please take the time to read all of the owner/operator literature supplied with your vehicle as soon as possible.

IMPORTANT

The information contained in this handbook covers all vehicle derivatives and optional equipment, some of which may not be fitted to your vehicle. Due to printing cycles, this handbook may include descriptions of options before they become generally available.

The vehicle options, hardware and software, are designed for the market in which the vehicle is intended for sale. If the vehicle is to be used in another geographical area, it may need modifications to suit local requirements. Land Rover is not responsible for the cost of any modifications.

The information contained in this publication was correct when it went to print. Subsequent vehicle design changes may result in a supplement being added to the literature pack. Updates can also be viewed on the Land Rover internet site at: www.ownerinfo.landrover.com.

In the interest of development, the right is reserved to change specifications, design or equipment at any time without notice and without incurring any obligations. This publication, or part thereof, may not be reproduced nor translated without our approval. Errors and omissions excepted.

Symbols used in this handbook



Safety warnings indicate either a procedure which must be followed precisely, or information that should be considered with great care, in order to avoid the possibility of personal injury.



Cautions indicate either a procedure which must be followed precisely, or information that should be considered with great care, in order to avoid the possibility of damage to your vehicle.



Identifies items that must be disposed of safely in order to prevent unnecessary damage to the environment.



Identifies features that can be adjusted, disabled or enabled by a Land Rover Dealer/Authorised Repairer.

© Land Rover 2010.

All rights reserved.

Published by Land Rover Technical Communications.

Contents

Introduction	2
Entering the vehicle	4
Exiting the vehicle	7
Front seats	
Rear seats	13
Steering wheel	14
Occupant safety	15
Exterior lights	28
Interior lights	30
Windows	31
Mirrors	33
Garage door opener	35
Wipers and washers	38
Instruments	40
Warning lamps	42
Heating and ventilation	45
Convenience features	50
Load carrying	52
Towing	55
Starting the engine	58
Gearbox	
Stability control	63
Brakes	
Tyre pressure monitoring system.	
Parking aid	69
Vehicle recovery	
Cruise control	73
Terrain response	
Hill descent control (HDC)	77
Audio system	79
DAB	91
Bluetooth telephone	97
Navigation system	107
Tyre renair kit	197

Fuel and retuelling	132
Maintenance	137
Fluid level checks	154
Technical specifications	160
Vehicle battery	165
Tyres	171
Fuses	174
Wheel changing	180
After a collision	183
Vehicle identification	184
Type approval	185
Controls overview	206