


REAR VIEW CAMERA

⚠ WARNING

Always turn and look before reversing. It remains the driver's responsibility to detect obstacles and estimate the vehicle's distance from them when reversing.



SL1634

When Reverse gear is selected, the touch screen automatically displays the view to the rear of the vehicle.

Overlaid on the rear view image are colored dashed lines representing the perimeter of the vehicle, solid lines predicting the path of the vehicle (based on the position of the steering wheel) and the distance information from the Parking aid system.

NOTICE

Some overhanging objects or barriers which could cause damage to the vehicle, may not be detected by the camera.

Note: A return icon is displayed in the bottom right hand corner of the touch screen. Touch this to revert to the previously viewed screen.

Rear view camera display on the touch screen will discontinue when either of the following apply:

- Drive is selected for longer than 15 seconds.

- Drive is selected and/or vehicle speed is greater than 11mph (18km/h).


SURROUND CAMERA SYSTEM

⚠ WARNING

It remains the driver's responsibility to detect obstacles and estimate the vehicle's distance from them when reversing.

The camera home page is accessed by touching **Cameras** on the **Home menu** screen.

With the engine running and Park or Neutral selected, the surround camera system uses 5 discretely placed cameras to assist in maneuvering the vehicle.



SL1739

1. Enlarge:

To enlarge a camera view, touch the image then touch the **Enlarge** soft key. Any two images can be selected and enlarged to view side-by-side on the screen.

When viewing two images, one of them can be selected to view as a full screen image. It can then be zoomed into and panned around using the magnifier and arrow icons.

2. Proximity View:

Selecting **Proximity View** will display a combination of three images from the front and passenger side cameras.

Note: Proximity view can be accessed at any time, by touching **Proximity View** on the **Camera** home page.

3. Special Views:

A selection of pre-set views can be displayed by selecting **Special Views**. They are provided to assist with difficult maneuvers and are:

- **Curb view:** Shows views from the two front cameras.


- **Junction view:** Shows views from the two side cameras.
- **Trailer view:** Shows the rear camera view.

4. Tow Assist:

Tow assist aids trailer reversing, by displaying information on the touch screen when reverse gear is selected.

Colored lines are displayed to indicate the predicted path of both trailer and vehicle.

Note: Tow assist requires a connected trailer to be fitted with a tracking target sticker. The sticker **must** be attached according to specific instructions. Ask your Land Rover Retailer for details.



SL1315

Note: This feature may not operate with all trailer designs. The towing electrical socket must be a Land Rover approved socket.

Tow assist becomes active when a trailer is attached to the vehicle and the trailer electrical plug is attached to the vehicle socket. The screen will display a choice for connection. Select **YES** to move to the setup screen. Select **NO** to return to the previous screen.

Information such as trailer length, number of axles and camera preference is required to finalise setup.

Once completed, the details are stored for future use.

***Note:** If the connection is not detected, setup can be manually prompted by touching the Tow assist icon on the Camera menu.*

5. Allows you to select any two of the views and enlarge to fill the screen.

CAMERA CLEANLINESS

If the color of the camera position arrow in the display changes from blue to red, the system has detected that the camera is dirty. Clean the camera in accordance with the guidelines given in the Maintenance section. **198, CLEANING**

THE INTERIOR