


### DUAL VIEW TOUCH SCREEN

Dual view touch screen option is a development of the LCD screen that enables the driver and front seat passenger to view two separate display modes.

Legal restrictions may not allow the driver to view moving images, as provided by TV and video formats, while the vehicle is in motion.

### HOW IT WORKS

Viewing angles for driver and front seat passenger are such that neither can view the full display that the other is viewing. However, there is an optimum viewing angle of 30 degrees where no cross over of images can be perceived. From this point, the closer to screen centre or screen side edges that the viewer moves to, the more likely cross over of images is. During normal use of dual view, image cross over is unlikely.



SL1657

Rear seat passengers may be able to see both views when dual view is active.

### DUAL VIEW SELECTION


When the ignition is switched on or the audio unit is turned on after being turned off, single view mode will be the default view.

To select dual view, press the dual view hard key on the fascia surround. See **111**, **AUDIO/VIDEO CONTROLS**.

Press again to display the dual view **Options** menu. From here, a change can be made to the viewing source or dual view can be cancelled.

If TV or a video format source were being viewed previously, the same source will be displayed.

## DUAL VIEW CONTROL MENU



SL1967

1. Select to cancel dual view and revert to the menu for the current video source (TV, DVD).
2. Select to view a list of all available video sources. Touch the relevant soft key to select an alternative source. The controls menu for that source will then be displayed.
3. Select to change the picture format (4:3, Zoom, 16:9). The next available format is displayed on the soft key.
4. Information on the current video source (e.g. TV channel and program name).
5. Select to switch the front passenger wireless headphone output on or off.
6. Select to cancel dual view: The touch screen reverts to the menu currently in use by the driver.
7. Select to retain audio for the video source while the display reverts to the menu currently in use by the driver.
8. Select to dismiss the dual view controls pop-up.
9. Seek up: Select to view the next channel on the channel list or the next track on CD or DVD.
10. Seek down: Select to view the previous channel on the channel list or the previous track on CD or DVD.

### DUAL VIEW TV OPERATION

If you would like to change the TV programme while the vehicle is moving, there are two methods available;

1. Press the dual view hardkey to display the control menu.

Select an alternative channel with soft keys (9) or (10) then touch the preview image in (4) to return to full view screen.

2. Press the steering wheel **MODE** button repeatedly to select TV. Press the forward or back buttons to move up or down your preset channels. The channel number will be displayed and after a short pause the TV programme will display.

**Note:** Not all channels are populated with a TV programme. Some channels broadcast only at pre determined times whereas others may broadcast continuously throughout the day and night.

### DUAL VIEW VIDEO OPERATION

When the video programme begins play, a root menu with information about the video programme and its content will be displayed on screen.

**Note:** Information and style may vary due to differing video media formats.

**Note:** If the chosen video media is CD or DVD, then a play/pause soft key is displayed between the Seek soft keys (9) and (10).