
## DAB RADIO CONTROLS



E135966

- DAB band selection. Touch to view and select a DAB band (DAB 1, 2 or 3). The radio will tune to the last used channel on that band. Touch again to close.
  - The DAB band selection box will close after 5 seconds without use.
- Display showing the current channel, the associated Ensemble and relevant DAB radio text.
- 3. Seek down: Short touch to seek previous available channel.
  - Long touch to seek previous available Ensemble. The first channel in the new Ensemble will be selected.
- **4.** Channel information: Touch to view DAB text and channel information.
- **5.** Seek up: Short touch to find the next available channel.
  - Long touch to find the next available Ensemble. The first channel in the new Ensemble will be selected.

- **6.** Settings: Touch to view the Settings menu:
  - Options: Select to activate/deactivate FM Traffic and DAB Link and to alter DAB country and format settings (with vehicle stationary).
  - Announcements: Select an alarm announcement and up to 3 other announcement types (traffic, news etc.) from the list. The selected announcements will interrupt the current programme when broadcast.
  - Audio settings: Select to enter the audio settings menu (see 112, AUDIO SETTINGS).
- Channel list: Touch to view a list of available Ensembles and channels. The list can be sorted by Ensemble, Channel, Subchannel or by Category.
  - If an Ensemble is selected from the list, all available channels from that ensemble will be displayed.
  - Sorting by Subchannel is only available when the current channel is broadcasting subchannels.

 If Category is selected, touch the chosen category to view corresponding channels, before making your selection from the list.

Once the desired selection has been made, select the Back soft key to return to the main DAB menu.

- Subchannel tier: If subchannels are broadcast by the current channel, this soft key will be active. Select to view available subchannels and then select the chosen subchannel from the list.
- Autotune: Select to scan for all available DAB Ensembles/channels. This needs to be done before using the DAB radio for the first time.

Autotune is also useful when travelling long distances, so regional Ensembles can be tuned

During Auto-tune, a pop-up shows tuning progress.

The Autotune process will not affect current presets, but some presets may not operate if the channel they relate to is no longer available (**No reception** displays).

- **10.** Station presets: Each DAB band has 6 preset positions.
  - Touch and release to tune the radio to the station stored on that preset.
  - Touch and hold to store the current station on that preset (the radio will mute while the station is stored).
  - Use the seek buttons on the steering wheel to select the next or previous preset station.

**Note:** If you attempt to select a preset channel that is now unavailable or invalid, **No channel found** is displayed.

## DIGITAL RADIO RECEPTION

DAB radio can significantly increase the number of radio channels/stations available. The DAB signals are transmitted to most major cities, towns and motorway networks.

Digital radio is transmitted from regional transmitters. Some local channels are not available outside the range of their transmitters. If you want to listen to local channels as you move around the country, use the auto-tune function (AUTO) to build new channel lists

**Note:** If any auxiliary electrical equipment is connected to the vehicle, then this may reduce the DAB radio sound quality.

## **ENSEMBLES**

Unlike AM/FM radio, DAB transmits several channels/stations on a single frequency. A group of channels is known as an ensemble. Some channels within the ensemble may have subchannels offering several listening options.

If reception is lost when the vehicle is in motion, the vehicle may be out of range of the ensemble. To build a new list of ensembles, select **Autotune**.