

DRIVER CONTROLS

1. Map reading lamp switch (41).
2. Main interior lamp switch (41).
3. Sunroof close switch (44).
4. Sunroof open switch (44).
5. High beam/direction indicator/trip computer switch (37/ 57).
6. Gearshift paddle (79).
7. Audio system control (112).
8. Instrument pack and message centre (51).
9. Vehicle information menu control (51).
10. Wiper/washer controls (42).
11. START/STOP button (76).
12. Audio system and controls (112).
13. Touch screen (108).
14. Left hand heated seat switch (15).
15. Tailgate release switch (9).
16. Hazard warning light switch.
17. Parking aid switch (92).
18. Right hand heated seat switch (15).
19. Climate controls (59).
20. Rotary gear selector - 8 speed transmission (79).
21. Stability control off switch (83).
22. Transfer gearbox switch (81).
23. Hill descent control (HDC) switch (106).
24. Air suspension control (84).
25. Terrain response control switch (103).
26. Electric parking brake (88).
27. Gear selector lever - 6 speed transmission (79).
28. Heated steering wheel switch (22).
29. Voice recognition and telephone switches (138/145).
30. Horn switches.
31. Cruise control/Adaptive cruise control switches (94/ 96).
32. Exterior mirror controls (46).
33. Window controls (44).
34. Rear window isolator (44).
35. Rear fog lamp switch (37).
36. Front fog lamp switch (37).
37. Instrument illumination dimmer control (37).
38. Main exterior lighting control (37).

