


SURROUND CAMERA SYSTEM

The camera home page is accessed from the **Home menu** screen. If Cameras has not been set as a short cut, touch **Extra Features** to display the list.

With the engine running and Park or Neutral selected, the surround camera system uses 5 discretely placed cameras to assist in manoeuvring the vehicle.



E136049

- 1. Enlarge:** To enlarge a camera view, touch the image then touch the **Enlarge** soft key. Any 2 images can be selected and enlarged to view side-by-side on the screen.

When viewing the two images, one of them can be selected to view as a full screen image. It can then be zoomed into and panned around using the magnifier and arrow icons.
- 2. Proximity View:** Touch to select a combination of 3 images from the front and passenger side cameras.

Automatic Proximity View: - Japan only: When Drive or Reverse is selected, the forward or rear view will be displayed. Once the vehicle speed 18 km/h (11 mph) or the return icon is pressed, the camera screen will disappear.

Note: Proximity view can be accessed at any time by touching Proximity View on the Camera home page.
- 3. Special Views:** A selection of pre-set views can be displayed by selecting **Special Views**. They are provided to assist with difficult manoeuvres and are:

 - **Kerb view:** Shows views from the 2 front cameras.
 - **Junction view:** Shows views from the 2 side cameras.
 - **Trailer view:** Shows the rear camera view.
- 4. Camera Setting - Japan only:** Touch to access the camera options page. To deactivate the Semi-auto camera functionality select **Off**. The Proximity view is now only accessible by manual activation using the **Proximity View** soft key.
- 5. Tow Assist:** Touch to display trailer guidance set-up screen.

PROXIMITY VIEW - MANUAL OPERATION

Selecting **Proximity View** will display a combination of three images from the front and passenger side cameras.

CAMERA CLEANLINESS

If the colour of the camera position arrow in the display changes from blue to red, the system has detected that the camera is dirty. Clean the camera in accordance with the guidelines given on page **178, CLEANING THE EXTERIOR**.

TRAILER GUIDANCE

Note: *Trailer guidance requires a connected trailer to be fitted with a tracking target sticker, which **must** be attached according to specific instructions. Ask your Dealer/Authorised Repairer for details.*



E134952

Note: *This feature may not operate with all trailer designs.*

Trailer guidance aids trailer reversing, by displaying information on the touch screen.

Trailer guidance becomes active when a trailer is attached to the vehicle and the trailer electrical plug is attached to the vehicle socket. The screen will display a choice for connection. Select **YES** to move to the setup screen. Select **NO** to return to the previous screen.

Note: *If the connection is not detected, setup can be manually prompted by touching the Tow Assist soft key on the Camera menu.*

TRAILER SETUP

On first use, the setup screens take the user through a series of configuration options for the connected trailer. Information such as trailer length, number of axles and camera preference is required to finalise setup. Once completed, the details are stored for future use.

CAMERA SYSTEM OPERATION

When a new or existing trailer configuration is selected, Trailer guidance automatically displays on the touch screen when reverse gear is selected. Coloured lines are displayed to indicate the predicted path of both trailer and vehicle.