


## Touch screen navigation

The screen requires only a light touch to operate the function. Excess pressure could result in damage.



Note: To access navigation press either the NAV hardkey on the surround or touch the Navigation icon on the touch screen.

- Use to enter a new destination. Provides a choice of options when entering a destination.
- Displays previous destinations entered. Previous destinations can be selected as a new destination.
- Allows selection of various options for the route.
- When a destination is set, the Range Rover logo in this position is replaced by a soft key which enables the last voice instruction to be repeated.
- Softkey is highlighted while voice guidance is enabled. Touch to turn voice guidance off.
- Calculates a detour from the current route.
- Advances to the main map screen.
- Move to other Navigation menu. There are two navigation menu screens. The second map screen features soft keys for **Stored locations**, **TMC**, **Map POI** and **Navigation set-up**. Use the **More** soft key to toggle between them.
- Cancel current route guidance.

On the second screen, **Stored locations** is used to manage the stored data. **TMC** (Traffic Message Channel) will provide data about road conditions and any events that may affect the current route. **Map POI** will turn on or off the POI (Point of interest) map icons and **Navigation set-up** is for setting personal preferences within the navigation system.

### Selecting navigation

When navigation is selected after the ignition is turned on, a caution screen is displayed. Touch **Agree**.

Note: At the first time of accessing the caution screen, set the required language.

### Setting a destination

Select **Destination entry**.

Select **Address** and enter address details using the keyboard. As each part of the address is displayed in full, select **OK** to confirm.

If the house number is not known, press **OK** - the mid-point of the road is then used as the destination.

When the system requirements are complete, the map screen showing the route settings and destination details will be displayed.

### Start guidance

Touch **Destination** to start route calculation.

There will be a choice of **3 Routes**, **Change route** or **Start navigation guidance**.

**3 Routes** will display three different route options on the map. To choose one of these options, select route **1**, **2** or **3** by touching the respective box displayed on the right side of the map.

Touch **Change Route** followed by **Route prefs** to change the route settings. If a destination is already set and extra via points are required along the route, touch **Waypoint** to add a waypoint as required.

When selections are complete, touch **Go**.

## Bluetooth® phones

Compatible Bluetooth® phones can communicate with the vehicle's inbuilt telephone system.

### Bluetooth® phone compatibility

For the latest list of compatible phones and their software, refer to [www.landrover.com](http://www.landrover.com). Select **OWNERS** then **Bluetooth®**.

Connection must be made with ignition on or engine running.

Use the following procedure in conjunction with your Bluetooth® phone manufacturer's instructions.

### Pairing and connecting using the cell phone

Note: The process of pairing and connecting a phone to the vehicle will vary depending on the type of cell phone used.

- Switch the ignition on and ensure that the touch screen is active.
- From the **Home menu**, select **Phone**.
- A menu will appear. If no phone is connected, select **Search new**, otherwise select **Change phone** and then select **Search new**.
- Select **Device to vehicle** option.

Note: The vehicle's Bluetooth® system is discoverable for only 3 minutes.

- Using the cell phone, search for Bluetooth® devices. On some phones, this is referred to as new paired device. See your phone's operating instructions for further information.
- When the vehicle's Bluetooth® system is discovered, begin the pairing process and follow the on-screen instructions.
- When requested, enter a PIN of your choice into the cell phone and vehicle system.
- Once your phone is paired it may automatically connect to the vehicle system. If not, use the device list shown on the touch screen or use the cell phone.

Note: Some cell phones require the Bluetooth® pairing to be set as 'authorised' or 'trusted' in order to automatically connect. Please refer to your phone's operating instructions for further information.

### Downloading phonebook entries

When a cell phone with phonebook download capability is paired and docked, its phonebook directory can be automatically downloaded to the vehicle system.

See **PHONEBOOK** in the Owner's Handbook for more information.

## Calls via the touch screen



With a paired and active cell phone press the **PHONE** button on the touch screen surround.

- Select **Digit Dial**, **Phonebook** or **Last 10**. With **Digit Dial** selected, use the keypad to enter the number. With **Phonebook** selected, choose a number from the downloaded phonebook. **Last 10** displays the previous 10 calls. Choose one to dial.
- Touch the connect icon to make the call. The icon will change to a connected call icon. Touch the icon to end a call.

## Calls via the steering wheel controls

See page 2, item 24.

- Connect. Press and release to send or accept a call or to access the last 10 dialled list. Press and hold to access the phonebook.
- Disconnect. Use to end or reject a call.
- Voice control talk button. The screen will display available options. Say 'Phone' and follow instructions.
- Press to increase call volume.
- Press to decrease call volume.
- Press to scroll up or down lists of calls or phonebook entries.