

LABEL LOCATIONS




Warning labels attached to your vehicle bearing this symbol mean: Do not touch or adjust components until you have read the relevant instructions in the handbook.



Labels showing this symbol indicate that the ignition system utilizes very high voltages. Do not touch any ignition components while the starter switch is turned on.

Additional information labels may also be found at the following locations:



SL1903

1. Hood locking platform - Air conditioning label.

2. Engine identification information. Stamped into engine mounting flange.
3. Engine information label. Top right side of engine cover.
4. Top of battery - Battery warning symbols.
5. The VIN (Vehicle Identification Number) is stamped on a plate which is visible through the lowest part of the left side of the windshield.

Note: If you need to communicate with a Retailer, you may be asked to quote the VIN number.

6. End of facia (passenger side) - Passenger air bag label.
7. Sun visor - Air bag label, vehicle handling label.
8. Base of right-hand B pillar - Tire pressure label, Air bag warning label.
9. Left-hand B pillar - VIN plate.
10. Inside gas filler flap - Fuel specification label.

It is important that you are familiar with these subjects to ensure that your vehicle and its features are used safely.

VEHICLE IDENTIFICATION NUMBER (VIN)

The VIN is a unique number which identifies your vehicle. Unlike the vehicle registration number it cannot be transferred and remains with your vehicle for its life.

A

ABS warning indicator	85
Accessories	157
Adaptive front lighting system (AFS)	47
AFS	47
Air bag label locations	217
Air bag service information	43
Air bag warning lamp	41
Air bags	38
components	39
deployment	41
maintenance	157
obstruction	40
occupant detection	42
operation	39
Alarm	
arming	16
arming confirmation	16
deactivating when triggered	11
disarming	11
Alarm deactivation	11
Ambient lighting	49, 107
Audio	
balance	111
CD	112
CD eject	110
CD load	110
fade	111
mode button	110
portable audio	124
satellite radio	118
seek up/down	110
settings	111
tone	111
touch screen operation	105
volume control	110
Audio overview	110
controls	110
Auto high beam	46
Autolamps	45
windshield wiper detection	46
Automatic climate control	71
controls	71

Automatic transmission	
automatic mode	82
Auxiliary input socket	126
Auxiliary power sockets	74

B

Battery care	178
Battery changing	181
Battery charging	181
Battery disconnection	181
Battery warning symbols	178
Beltminder	31
Blind spot monitor	57
sensor blockage	58
system fault	58
Bluetooth	136
audio devices	124
compatibility	136
connecting a phone	139
connecting an audio device	126
pairing a phone	139
pairing an audio device	126
Boost starting	179
Booster cables	179
Booster seats	33
Brake fluid	
topping up	176
Brake fluid check	175
Brakes	
principle of operation	85
Bulb changing	160
Bulb specification chart	194
Bulbs	
replacing a xenon bulb	161

C

California proposition 65 warning	178
Camera systems	
hitch assist	108
surround cameras	108
Capacities	191
Car wash	166

CD	112	Cleaning	
controls	122	carpets	168
eject	110	cloth and fabric	167
load	110	glass surfaces	167
loading	112	mats	168
MP3 playback	124	rear screen	167
playback	122	wheels	167
repeat	122	Cleaning stubborn stains	166
shuffle	122	Cleaning the exterior	166
skip/scan	122	after off-road driving	166
supported formats	112	Cleaning the interior	167
touch screen operation	122	air bag module covers	168
track list	122	audio system	169
virtual player	112	instrument panel	169
virtual store	122	leather care	167
Changing a bulb	160	seat belts	168
general information	160	touch screen	169
Changing a fuse	183	Climate control	71
Changing a road wheel	209	water deposits	72
operating the jack	211	Clock	63, 106
temporary spare wheel	210	Connecting a phone	139
wheel changing safety	210	Connecting a portable media device	125
wheel chocks	210	Connecting auxiliary devices	126
Changing a wheel	211	Coolant check	174
Changing the vehicle battery	181	Courtesy delay (headlamps)	45
disconnecting	181	Cruise control	89
effects of disconnecting	181	auto switch off	90
Charging the vehicle battery	181	canceling	89
Child locks	27	setting the speed	89
Child seats	31	Cup holders	73
anchor points	35		
check list	33	D	
LATCH anchor points	35	Data recording	160, 216
positioning	34	Daytime running lamps	46
safety	33	Dimensions	193
seat belt locking mechanism	32	Disability modifications	44, 157
tether anchorage points	36	Disarming the alarm	
tether straps	36	deactivating the alarm when triggered	11
		smart key failure	11
		Display icons	105

Door locks	18	Engine starting	80
global entry	10	no engine cranking	80
keyless entry	10	Engine switch off	
multi point entry	10	with the vehicle moving	80
single point entry	10	Essential towing checks	78
unlocking	8	Event data recording	216
Door mirrors	55	Exterior mirrors	55
Drawbar dimensions	79	adjusting and folding	55
Drive selector	82	mirror dip when reversing	56
Drive-away locking	17	External temperature	63
Driver information center	63	F	
Driving after a collision	216	Facia	232
before starting or driving	216	Fastening the seat belts	27
DVD		Flat spots	205
controls	128	Fluids	
supported formats	112	brake fluid top-up	176
DVD discs	112	Front seats	
E		correct adjustment	20
Easy entry and exit	22	electric	19
Easy route	147	head restraints	22
Electric seats	19	memory seats	21
seatback tilt	23	Fuel	
Electric windows		empty fuel tank	155
overriding anti-trap protection	54	filler	156
window reset	54	maintenance	160
Electronic Brake Distribution (EBD)	86	octane rating	154
Emergency Brake Assist (EBA)	85	running out of fuel	155
Emission control	159	Fuel filler flap	155
Engine		Fuel gauge	63
fuel	154	Fuel quality	154
rolling re-start	80	ethanol	155
Engine compartment overview	172	methanol	155
Engine coolant check		MTBE	155
checking the coolant level	174	reformulated gasoline	155
topping up the coolant	174	Fuel specification	156
Engine fails to start	81	Fuse box locations	182
Engine oil check	172	Fuse specification chart	
checking the oil level	172	engine compartment fuse box	184
oil specification	174	luggage compartment fuse box	189
topping up the oil	173	passenger compartment fuse box	186
Engine specifications	190		

Fuses	182	Head restraints	
access	182	front seats	22
changing	183	rear seats	25
engine compartment	184	Headlamp leveling	47
locations	182	halogen headlamps	47
luggage compartment fuses	189	Headlamp washers	51
passenger compartment fuses	186	Headlamps	45
replacement	183	exit delay	45
		low beam	45
G		Heated mirrors	56, 72
Garage door opener	60	Heated steering wheel	26
Garage door transceiver		Heating	71
before programming	60	Hill descent control	95
entry gate programming	61	operation	95
erase all programming	61	Hill start assist	94
information and assistance	62	Hill start brake hold	96
programming	60	Hitch assist camera	108
reprogramming a single garage		Home menu	104
door opener button	61	Homelink	60
rolling code devices	61	before programming	60
Gearbox		entry gate programming	61
CommandShift mode	83	erase all programming	61
drive mode	83	information and assistance	62
drive selector	84	programming	60
drive selector fails to elevate	84	reprogramming a single garage	
kick-down	84	door opener button	61
neutral	83	rolling code devices	61
reverse	83	Hood lock	171
reverse gear	83		
sport mode	83		
Gearbox fault	84	I	
Gradient acceleration control	94	Ignition	
Gradient release control	96	rolling re-start	80
		switching off with the vehicle moving	80
		Ignition on	80
		Information messages	65
		Installing an LATCH child restraint	35
		Instrument panel overview	63
		Interior lamps	48
		rear interior lighting	48
		Interior lighting	49
H			
Hazard warning flashers	47		
HD radio	121		
auto switching	121		
poor reception	121		
secondary services	121		
HDC	95		

Interior mirror	56	Load limit	208
auto dimming	56	Locking	
manual dimming	56	child locks	27
iPod connection	124	drive-away locking	17
J		keyless locking	17
Jacking the vehicle	211	mislock	16
Jump starting	179	valet mode	107
K		Locking and unlocking	
Keyless entry	10	confirmation	16
Keyless locking	17	from inside the vehicle	18
L		valet mode deselecting	12
Label locations	217	valet mode selecting	17
LATCH		Locks	
anchor points	35	changing the smart key battery	14
anchor points installation	35	Low beam	45
child seats	35	Lubricants and fluids	190
child seats installation	35	Luggage anchor points	76
LED interior lights	49	Luggage area	75
Licensing information		M	
DivX	113	Maintenance	157
Dolby	113	air bag system	157
dts	113	arduous conditions	158
gracenote	113	brake fluid top-up	176
Lighting	45	dynamometer testing	159
exterior	45	emission control	159
Lighting control		fuel system	160
headlamp courtesy delay	45	general information	158
headlamps	45	owner	158
Lights	45	regular checks	158
adaptive front lighting (AFS)	47	rolling road testing	159
auto high beam	46	safety	159
exterior	45	technical specifications	190
headlamp courtesy delay	45	Mapping data	143
headlamps	45	Memory seats	
headlamps exit delay	45	easy entry and exit	22
low beam	45	front seats positions	21
sidelights	45	Menu	
windshield wiper detection	46	touch screen	104
Load carrying	75	Message center	63, 65
		Messages	65

Mirrors	
automatic powerfold	55
blind spot monitor	57
exterior	55
heated	56
operation	55
powerfold	55
reverse auto-dip	56
MP3	124
Multi point entry	10

N

Navigation	
cancel route guidance	147
cancel voice guidance	147
controls	144
coordinates	148
digitised area	143
easy route	147
emergency search	148
learn route	147
main menu	144
mapping data	143
memory points	147, 148
points of interest	147
retailer locations	149
screen modes	146
search area	146
setting a destination	146
split screen map	145
starting guidance	146
things you need to know	143
traffic message channel (TMC)	150
traffic message channel (TMC) icons	150
turning on	143
vehicle position error	143
News announcements	117

O

Occupant detection	42
Octane rating	154
Off road recovery	214

Off-road driving	
wading	94
Off-road driving guidance	93
Oil check	172
Oil specification	174
Opening and closing the hood	171

P

Paint	
damage repair	167
Pairing a phone	139
Panoramic roof blind	53
Park slot detection	
principle of operation	101
system fault	103
Parking aid	
cleaning the sensors	99
principle of operation	98
rear view camera	99
sensor care	99
towing	78, 99
Parking brake	
applying	86
releasing	86
Parts	157
Passport to Service	158
Phone	136, 138
Phonebook	141
POI voice commands	135
Portable audio	124
bluetooth	126
connecting a bluetooth device	126
connections	124
playing a bluetooth device	126
playing a device	125
Portable media	124
connections	124
Powered tailgate	
opening clearance	78
opening height	14
operation	12
while towing	78

Proposition 65 warning	178	Refueling	
R		fuel filler	156
Radio		fuel specification	156
alternative frequencies (AF)	117	tank capacity	156
autostore	116	Remote control	
channel up/down	116	changing the battery	14
controls	116	unlocking	8
enhanced other networks (EON)	117	Replacing wiper blades	169
HD radio	121	Reporting safety defects	7
news announcements	117	vehicle defects	7
Radio Data System (RDS)	117	Restraints	31
regionalisation (REG)	117	Rolling re-start	80
satellite	118	Roof blind	53
settings	116	Roof rack	157
station list	116	Roof racks	75
station presets	116	maximum load	75
text	116	vehicle stability	75
touch screen operation	116	RSE	
traffic announcements	116, 117	introduction	130
wave band selection	116	remote control	132
Rain sensor	51	settings	131
Rear loadspace	75	supervisor screen	130
Rear media	130	Running out of fuel	155
head phones	133		
remote control	132	S	
Rear seat entertainment		Safety	
remote control	132	air bags	38
Rear seat entertainment (RSE)	130	child locks	27
Rear seats		child seats	31
folding	24	child seats check list	33
head restraints	25	seat belt checks	30
Rear view camera	99	using a telephone	136
Rear view mirrors	55	Safety precautions	154
Rear window washer	52		
Rear window wiper	52		
Recommended towing weights	77		
Recovery by towing	214		
Recovery by transporter	213		

Satellite radio	118	Snow chains	205
announcements	118	TPMS inflation compensation	206
autotune	118	Spare wheel removal	209
band selection	118	Speech activation	134
channel information	118	Speedometer	63
channel list	118	SRS (Supplementary restraint system)	38
channel up/down	118	Stability	6
controls	118	Stability control	91
reception	120	Starting navigation guidance	146
settings	118	Starting problems	81
song seek	120	Starting the engine	80
station presets	118	no engine cranking	80
subchannels	118	Steering wheel	
subscription (SIRIUS)	119	adjusting position	26
text	118	heated	26
touch screen operation	118	telephone controls	140
Say what you see	134	Stoddard solvent for cleaning	166
Seat belt locking mechanism	32	Storage areas	73
Seat belt reminder	30	Supplementary restraints system	38
Seat belts	27	Switching off the engine	
beltminder	31	with the vehicle moving	80
fastening a seat belt	27	Switching the ignition on	80
height adjustment	27		
releasing a seat belt	27	T	
safety	30	Tachometer	63
safety checks	30	Tailgate	
use during pregnancy	27	opening height	14
warning lamp	30	operating	12
Seats		powered	12
child seats	31	setting the opening height	14
Service interval indicator	65	Technical specifications	
Servicing		capacities	191
interval indicator	65	engine data	190
Settings	63	fuel specification	156
Sidelights	45	lubricants and fluids	190
Single locking	16		
Single point entry	10		
SIRIUS subscription	119		
Sitting in the correct position	20		
Smart key			
changing the battery	14		
unlocking	8		

Telephone	136	Tires	
bluetooth	136	age degradation	205
call divert	138	correct load limit.	208
call volume	140	flat spots.	205
changing phone.	140	for winter use	205
compatibility	136	glossary of terms	207
connecting.	139	markings.	200
controls.	138, 140	pressure check	203
digit dial.	138, 140	pressure compensation chart	204
ending a call	138	pressure compensation for	
general information	136	temperature changes	204
last 10 option.	141	pressures	202
making a call	138	punctures	203
pairing	139	quality grades	206
phonebook.	141	replacing.	203
safety.	136	speed ratings	201
status.	138	temperature grading	206
touch screen icons	140	tire care.	201
touch screen operation	138	tire pressure lable.	202
voice mail	138	TPMS inflation compensation.	206
Temperature gauge	63	traction grading	206
Terrain response		tread wear grading	206
controls.	93	using snow chains	205
Tether straps for child seats	36	using traction devices.	205
Tire pressure label location	217	valves	203

Touch screen	104	Trailer leveling	77
audio controls	105	Trailer stability assist	78
care	107	Transmission	
CD controls	122	CommandShift mode	83
connecting a phone	139	drive mode	83
deselecting valet mode	12, 107	drive selector	84
display icons	105	drive selector fails to elevate	84
home menu	104	kick-down	84
language settings	106	neutral	83
pairing a phone	139	reverse	83
pop-ups	105	reverse gear	83
radio controls	116	sport mode	83
satellite radio controls	118	Transmission fault	84
screen settings	106	Transmitter locations	195
selecting valet mode	17, 107	Transporter recovery	213
set-up	106	Trip computer	65
system settings	106	average fuel consumption	65
telephone controls	138	average speed	65
telephone icons	140	changing the display	65
touch screen use	105	ML-km (also Miles-liter)	65
video media controls	128	range	65
voice settings	106	service interval indicator	65
Tow recovery	214	trip distance	65
Towing		Trip recorder	63
electrical connections	78	Turning on the ignition	80
essential checks	78		
tailgate clearance	78	U	
trailer leveling	77	Unlocking with keyless entry	10
weights	77	Upholstery care	167
Towing a trailer	77	USB devices	124
Towing for recovery	213	USB video files	112
Towing points		Using booster cables	179
front and rear towing eyes	213	Using cruise control	
TPMS		engaging	89
full size spare wheel	198	increasing speed	89
Inflation compensation with		reducing speed	89
snow chains	206	resuming a set speed	90
operation	197	suspending	90
replacement sensor	199	Using HDC	95
Traction control	92	selecting HDC	95
Traction devices	205	Using seat belts during pregnancy	27
Traffic announcements	117		
Trailer hitch	79		

Using stability control	91	Voice control	134
deactivating	91	command list	134
DSC	91	help mode	134
reactivating	91	operating guide	134
Using terrain response	93	training	135
before driving off-road	93	tutorial	134
override options	94	user recognition	135
Using the parking aid		voice button	134
sensor care	103	voice recognition	135
system fault	99	voicetags	135
Using the smart key		Voice mail	138
locking	16	Voice settings	106
Using traction control	92	recognising a particular accent	106
Electronic Traction Control (ETC)	92	recognising a particular voice	106
		teaching the system	106
V		Voicetags	135
Valet mode	107	Volume control	110
deselecting	12, 107	Volume presets	106
PIN entry	107		
selecting	17, 107	W	
Vehicle battery changing	181	Wading depth	94
Vehicle battery charging	181	Warning lamps	67
Vehicle battery disconnection	181	primary warnings	67
Vehicle build plate location	217	seat belt	30
Vehicle identification number (VIN)	217	secondary warnings	67
Vehicle information and settings menu	63	status check at ignition on	67
Vehicle recovery	213	system status	67
off road	214	Warning messages	65
Vehicle settings	63	Washer fluid check	177
Vehicle stability	6	topping up the fluid	177
Ventilation	71	Washer jets	
Video media player		cleaning	177
angle	128	Washers	
controls	128	drip wipe	51
GOTO	128	headlamp	51
settings	128	rear	52
subtitles	128	Washing	166
tools	128	cloth and fabric	167
VIN label locations	217	glass surfaces	167
Voice commands		rear screen	167
POI	135	wheels	167
		Weights	192

Wheel changing	211
Wheel chocks	210
Wheels	
cleaning	167
Wheels and tires	
technical specifications	194
Windows	53
anti-trap protection	54
operation	53
resonance	54
roof blind	53
window isolator	53
Windshield washer jets	
blocked jets	177
Windshield wiper detection	46
Windshield wipers	50
drip wipe	51
rain sensor	51
single wipe	50
speed sensitive	51
winter park position	51
wiper operation	50
Wiper blade replacement	169
Wiper detection	46
Wipers	
rear	52

X

Xenon bulb replacement	161
----------------------------------	-----

