
Notepad

USING NOTEPAD

Notepad is a feature for recording short messages as memory aids or reminders.



You can record up to 10 notes for up to 30 seconds each in length. Press and hold the voice button shown in the illustration until **LISTENING** appears in the message centre, then give the relevant command (see table below).

The voice recording will automatically be stopped if the note is longer than 30 seconds.

To stop voice recording at any time, press the voice button again.

LAN1130

COMMAND	SYSTEM RESPONSE	ACTION
Notepad record.	The system gives a beep to indicate the start of recording.	You may start your recording after the beep. To stop recording, press the steering wheel voice button
Notepad play.	Notepad audio will read out each note in turn. You can say Replay , Delete or Cancel after each beep, or remain silent to hear the next note.	Saying Replay will replay the previous message. Saying Delete will delete the previous message. Saying Cancel will end the notepad session.
Notepad clear.	Do you want to clear the notepad?	Say Yes to delete all stored notes. Say No to cancel the command.
Notepad help.	The system will read out Notepad information and all the commonly used commands.	