


Navigation system


- 9. **Return to map:** Advances to the main map screen.
- 10. **Detour:** Allows a detour from the current route.
- 11. **Nav set-up:** Settings for the navigation system.
- 12. **Route options:** Allows selection of various options for the route.

- 13. **TMC (Traffic Message Channel):** Not used for entering a destination but, when enabled, will provide data about road conditions and any events that may affect the journey.
- 14. **Stored locations:** Manages the stored locations.

MAP SPLIT SCREEN



E141772

- 1. Compass. Press to select: north up, heading up or bird's eye map style.
 - 2. TMC (Traffic Message Channel) signal. Without a diagonal bar, a signal is being received; with a diagonal bar, a signal is not being received.
 - 3. Next direction display. When intersection map view has been switched off, touch icon to view again.
 - 4. Current vehicle position and direction.
 - 5. Right map view, scale/zoom setting.
 - 6. Current location.
 - 7. GPS signal indicator.
 - 8. Screen selection.
 - 9. Left map view, scale/zoom setting.
 - 10. Opens Navigation menu 1 of 2 screen.
 - 11. Distance/time to destination.
 - 12. TMC event (traffic congestion).
-  Touch to close the Intersection and Motorway junction view. The previously displayed map is shown after closing.