



- 9. **Return to map:** Advances to the main map screen.
- 10. **Detour:** Allows a detour from the current route.
- 11. **Nav set-up:** Settings for the navigation system.
- 12. **Route options:** Allows selection of various options for the route.
- 13. **TMC (Traffic Message Channel):** Not used for entering a destination but, when enabled, will provide data about road conditions and any events that may affect the journey.
- 14. **Stored locations:** Manages the stored locations.

## MAP SPLIT SCREEN



E141772

1. Compass. Press to select: north up, heading up or bird's eye map style.
  2. TMC (Traffic Message Channel) signal. Without a diagonal bar, a signal is being received; with a diagonal bar, a signal is not being received.
  3. Next direction display. When intersection map view has been switched off, touch icon to view again.
  4. Current vehicle position and direction.
  5. Right map view, scale/zoom setting.
  6. Current location.
  7. GPS signal indicator.
  8. Screen selection.
  9. Left map view, scale/zoom setting.
  10. Opens Navigation menu 1 of 2 screen.
  11. Distance/time to destination.
  12. TMC event (traffic congestion).
-  Touch to close the Intersection and Motorway junction view. The previously displayed map is shown after closing.