


## LUGGAGE ANCHOR POINTS



To assist in safely securing large items of luggage, four fixing points are located in the rear loadspace floor.



**All items carried in the luggage area should be properly secured.**

**Note:** A range of approved luggage retention accessories are available from your Land Rover Dealer/Authorised Repairer.