

**Note:** *The master unlock button is inhibited when the vehicle is locked with the Smart Key.*

### **MISLOCK**

When attempting to lock the vehicle, if one or more of the doors, the bonnet or the tailgate are not fully closed, the vehicle will fail to lock and the horn will emit two tones. The vehicle will not fully lock until all doors, the bonnet and the tailgate are completely closed.

### **DEACTIVATING THE ALARM WHEN TRIGGERED**

If the alarm has been triggered it can be deactivated by pressing the Smart Key unlock button, or by positioning the Smart Key underneath the steering column (see **76, IF THE ENGINE FAILS TO START**).