


After touching **Agree**, the touch screen will display the previously displayed map view. This will show the current vehicle position. Touch the **Nav menu** soft key to display the main menu screen.

At this point, the first time user should set up personal preferences in the **Nav set-up** area. These settings are applied whenever navigation is used.

MAIN MENU



E141771

1. **More...:** Displays the other Nav menu screen.
2. **Cancel guidance:** Cancels current route guidance.
3. **Destination entry:** Provides a choice of options for entering a destination.
4. **Previous destination:** Displays previous destinations entered.
5. **Display/Hide POI:** Turns the POI (Point Of Interest) icons on the map on/off.
6. When a destination is set, the Range Rover logo is replaced by a soft key which enables the last voice instruction to be repeated.
7. **Route voice guidance:** Allows the voice guidance messages to be turned off for the current journey. The soft key is highlighted while voice guidance is enabled.
8. POI shortcuts: Touch icon to list available POIs close to the vehicle position.
9. **Return to map:** Returns the map to the previous view.
10. **Detour:** Displays alternative routes to the destination.
11. **Nav set-up:** Allows the user to set up personal preferences.
12. **Route options:** Allows the user to select different route options.
13. **TMC:** Displays real-time traffic information.
14. **Stored locations:** Displays a list of previously entered destinations.