

Suspension

To lower the vehicle press and hold button **(1)**, then press and hold button **(3)**

Note: *If the starting height is above or below normal height, movement will cease when normal height is reached. Release the Smart Key buttons and press again to continue.*

ADAPTIVE DYNAMICS

If the general warning lamp illuminates (see **55, GENERAL WARNING/INFORMATION MESSAGE (AMBER)**) and the message **ADAPTIVE DYNAMICS FAULT** is displayed in the Driver information center, some reduction in ride comfort may be experienced. If the fault persists, consult a Land Rover Retailer/Authorized Repairer.