


OPENING AND CLOSING THE BONNET



SL1817

Opening

1. Pull the bonnet release lever, located in the left side front footwell.
2. Lift the bonnet safety catch, located below the centre point of the bonnet, then raise the bonnet.

Closing



Do not drive with the bonnet retained by the safety catch alone.

3. Lower the bonnet until the safety catch engages. Using both hands, press the bonnet down until the catches click. Check that both catches are engaged by trying to lift the front edge of the bonnet.

POISONOUS FLUIDS

Fluids used in motor vehicles are poisonous and should not be consumed or brought into contact with open wounds.

For your own safety, always read and obey all instructions printed on labels and containers.

USED ENGINE OIL

Prolonged contact with engine oil may cause serious skin disorders, including dermatitis and cancer of the skin. Always wash thoroughly after contact.



It is illegal to pollute drains, water courses or soil. Use authorised waste disposal sites to dispose of used oil and toxic chemicals.