

## TRAILER DIRECTION INDICATORS (GREEN)



Illuminates briefly when the ignition is switched on and extinguishes when the engine is started.

If a trailer is attached, the warning lamp will flash in conjunction with the direction indicator warning lamp. If the lamp fails to flash, the direction indicator bulb on the trailer may be faulty.

## HIGH BEAM ASSIST (GREEN)



Illuminates when the High beam assist feature is enabled.

## HIGH BEAM (BLUE)



Illuminates when the high beam headlamps are switched on or flashed.

## ECO STOP/START (GREEN)



Illuminates when the Stop/Start system is activated. The engine will automatically switch off when the vehicle comes to a stop, neutral is selected and the clutch is fully released.