
USING VOICE CONTROL

Note:

The voice system has been designed to recognise a number of languages. However, Land Rover cannot guarantee the system will be compatible with every accent group within those languages. Please speak to your Dealer/Authorised Repairer about testing the Voice System for compatibility with a particular accent group.



1. Voice button: Press briefly to start a voice session. A pop up will appear on the touch screen. Press and hold to cancel a voice session.

   Note: *Briefly press the Voice button during a voice session, to interrupt audible feedback. Wait for the tone to sound before giving the next command.*

2. Voice symbol: Indicates that a command is available. Wait for the symbol to appear and a tone to sound before using the command.

3. Command list: Appears on the pop up panel, providing feedback and available commands at each stage of the voice session. Say an available command.

   Note: *As the commands are listed before the system is ready to listen, it is important to wait for the voice symbol to appear alongside the relevant command, before using the command.*

4. When displayed, say **Cancel** to cancel the current voice session.

5. When displayed, say **Help** to get assistance during a voice session.

Note: *The currently selected user (User 1 or User 2) is identified at the bottom of the command list.*

Note: *If a listed item is longer than the available space on the menu,* ***...>*** *will appear. Use the seek controls on the steering wheel to view the entire entry. See* ***112, TOUCH SCREEN AUDIO/VIDEO CONTROLS*** *items 14 and 15. Also see* ***164, STANDARD AUDIO CONTROLS*** *items 19 and 20.*