


## MANUAL SEATS



SL1713



**Do not adjust the seat while the vehicle is moving. Doing so could cause loss of vehicle control and personal injury.**

1. Forward and back adjustment.
2. Height adjustment.
3. Backrest adjustment.
4. Head restraint adjustment (where fitted).