
TELEPHONE SYSTEM OVERVIEW



1. **Change phone**. Touch to search new or change to another paired phone.
2. **Last 10**. Select to access the last 10 dialled, received and missed calls.
3. **Phonebook**. Select to access the downloaded phonebook.
4. **Digit Dial**. Select to access Digit Dial mode.
5. Touch and hold soft key 1 to retrieve your Voice mail.
6. Status display. Displays the name and/or number dialled and call duration.
7. Call Connect/Disconnect icons. Touch to send/accept or end/reject a call.
8. **Settings**. Access Voice mail set up, Answer options and Phone options.
9. **Mute microphone**. Select to initiate Privacy mode. While selected, the caller will not hear you talking.
10. Touch to activate/deactivate Auto reject. When active, any incoming calls will be rejected or diverted to voice mail (depending on mobile phone settings).
11. **Use handset**. Select to switch the call to your mobile phone.
12. **Delete**. Touch and release to delete the last entered digit. Touch and hold to delete the whole entered number.