


## TELEPHONE SYSTEM OVERVIEW



SL1857

- 1. Change phone.** Touch to search new or change to another paired phone.
- 2. Last 10.** Select to access the last 10 dialed, received and missed calls.
- 3. Phonebook.** Select to access the downloaded phonebook.
- 4. Digit Dial.** Select to access Digit Dial mode.
- Touch and hold soft key 1 to retrieve your Voice mail.
- 6. Status display.** Displays the name and/or number dialed and call duration.
- Call Connect/Disconnect icons. Touch to send/accept or end/reject a call.
- 8. Settings.** Access Voice mail set up, Answer options and Phone options.
- 9. Mute microphone.** Select to initiate Privacy mode. While selected, the caller will not hear you talking.
- 10.** Touch to activate/deactivate Auto reject. When active, any incoming calls will be rejected or diverted to voice mail (depending on mobile phone settings).
- 11. Use handset.** Select to switch the call to your mobile phone.
- 12. Delete.** Touch and release to delete the last entered digit. Touch and hold to delete the whole entered number.