

As mobile phones have a wide range of audio and echo characteristics, it may take a few seconds for the vehicle system to adapt and deliver optimum audio performance. To achieve this, it may be necessary to reduce the in-vehicle volume and ventilation fan speed slightly.

STEERING WHEEL ICONS



Connect. Press and release to send or accept a call or to access the last 10 dialled list. Press and hold to access the phonebook.



Disconnect. Use to end or reject a call.



Voice control talk button.



Press to increase call volume.



Press to decrease call volume.



Press to scroll up or down lists of calls or phonebook entries.

