


MAIN MENU



E141771

- 1. More...:** Displays the other Nav menu screen.
- 2. Cancel guidance:** Cancels current route guidance.
- 3. Destination entry:** Provides a choice of options for entering a destination.
- 4. Previous destination:** Displays previous destinations entered.
- 5. Display/Hide POI:** Turns the POI (Point Of Interest) icons on the map on/off.
- 6.** When a destination is set, the Range Rover logo is replaced by a soft key which enables the last voice instruction to be repeated.
- 7. Route voice guidance:** Allows the voice guidance messages to be turned off for the current journey. The soft key is highlighted while voice guidance is enabled.
- 8.** Quick POI shortcuts. This provides the option to quickly enter a destination of a local POI. The categories can be changed in the Navigation setup menu.
- 9. Return to map:** Advances to the main map screen.
- 10. Detour:** Allows a detour from the current route.
- 11. Nav set-up:** Settings for the navigation system.