Remove any snow, ice or frost from the screen, around the wiper arms and blades and the screen scuttle, before operating the wipers.

Note: *Front wipers will not operate while the bonnet is open and vehicle speed is below 3 km/h (2 mph).*

Note: *If wiper blades become stuck or jammed, an electronic cut-out will temporarily halt wiper operation. If this happens, switch off the wipers and the ignition. Clear any obstructions and free the wiper blades, before attempting to switch on the ignition.*

RAIN SENSOR

Ensure that the wipers are switched off before entering a car wash. If the rain sensitive wipers operate during the car washing process, damage may occur to the wiper mechanism.

The rain sensor is able to detect the presence and amount of rain/dirt/snow on the windscreen and automatically activates the windscreen wipers accordingly. Static droplets may not be detected on initial start-up, use a single wipe to clear the screen.

To activate the rain sensitive wipers, move the wiper stalk to the rain sensor position (**4**). A single wipe will be actioned.

Adjust the rain sensitivity collar (**1**) as required. Increasing sensitivity while position (**4**) is selected will action a single wipe.

If a front door is opened while the wipers are operating, the wipers will be disabled. Operation will restart when the door is closed again.

SPEED-DEPENDENT WIPERS

If vehicle speed drops below 6 km/h (3.7 mph) with the wipers operating in positions (**2**) or (**3**), the wipers will switch to the next lowest speed. When vehicle speed increases to over 6 km/h (3.7 mph), the original wiper speed setting is restored automatically.

DRIP WIPE

If the drip wipe function is configured, the wipers will operate four seconds after a wash/wipe cycle has finished, to clear any remaining drips from the windscreen.



This function can be enabled/disabled by your Dealer/Authorised Repairer.

WIPERS WINTER PARK POSITION

The wipers can be set to park in a higher position than normal. This allows the wiper blades to be lifted from the screen to prevent freezing. The 'Wipers winter park' option can be selected from the settings menu. See **59, VEHICLE INFORMATION AND SETTINGS MENU**.

HEADLAMP WASHERS

The optional headlamp power wash operates automatically with the windscreen wash and will operate only If the headlamps are switched on and there is sufficient washer fluid in the reservoir.

Headlamp wash operates every fourth operation of the screen washers, provided the headlamps are still switched on and approximately ten minutes have elapsed since the last headlamp wash.

Switching the headlamps or ignition off and back on again, will reset the cycle.

See **203, WASHER FLUID TOPPING UP**.