

**Note:** Options such as **Repeat** and **Mix** relate to the device currently playing, they will not apply to any subsequent device.

The 3.5mm AUX socket allows additional equipment (e.g. personal stereos MP3 player, hand-held navigation unit, etc.) to be connected to the audio system.

The auxiliary power socket, situated next to the auxiliary jack, can be used to power or charge any suitable device.

**Note:** iPod shuffle may be connected via the AUX socket.

**Note:** On vehicles fitted with rear seat entertainment, additional Audio/Visual sockets are provided. This allows auxiliary equipment (such as a video game console) to be linked to the rear DVD screens. For installation information, please refer to the manufacturer's instructions.

## PAIRING AND CONNECTING A BLUETOOTH® MEDIA DEVICE

For further information on Bluetooth® and device compatibility, see **143, BLUETOOTH® INFORMATION**.

### Using your media device

**Note:** The process of pairing and connecting your media device with the vehicle using the media device, will vary depending on the type of media device.

1. Switch the ignition on and ensure that the touch screen is active.
2. From the home menu, select **Audio/Video**, then **My Music**.
3. Touch **Blue-tooth**.
4. A menu will appear. Select **Change device**.
5. Select **Device to vehicle** option.

**Note:** The vehicle's Bluetooth® system is discoverable for only 3 minutes.

6. Using the media device, search for Bluetooth® devices.

On some devices, this is referred to as new paired device. See your operating instructions for further information.

7. When the vehicle's Bluetooth® system is discovered, follow the on-screen instructions. Select **Yes** when prompted, to confirm the pairing.

Either your device or the vehicle system will ask for a PIN (Personal Identification Number). When prompted, enter a PIN of your choice and select **OK** to confirm.

8. Enter the same PIN into the other device.
9. Once your device is paired and connected to the system, a confirmation message will be displayed, before switching to the **My music**, Bluetooth® view.

**Note:** Some media players do not automatically connect and need to be manually connected, via the device or by using the **Change device** option.

### Using the touch screen

1. Switch on your device's Bluetooth® connection. Make sure that it is in Bluetooth® discoverable mode, sometimes referred to as find me mode (see your device's operating instructions for more information).
2. Switch the ignition on and ensure that the touch screen is active.
3. From the home menu, select **Audio/Video**, then **My Music**.
4. Touch **Blue-tooth**.
5. A menu will appear. Select **Change device**.
6. Select **Vehicle to device** option.
7. Identify your device from the displayed list and select the corresponding **Pair and connect** option.