

Note: If more than 5 devices are detected, it may be necessary to use the scroll bar to see the entire list.

- When prompted, enter the PIN code into your device. See your device operating instructions for further information.
- Once your device is paired and connected to the system, a confirmation message will be displayed before switching to the My music, Bluetooth® view.

Note: Due to the duration of a Bluetooth® search, it is advised that the time-out to home screen feature is switched off before attempting to search for Bluetooth® devices. This setting can be changed within **Vehicle**, **Syst settings**, **Display set**, **Timeout to home screen**.

LOSS OF CONNECTION

If a loss of connection between the vehicle and the Bluetooth® device occurs, a pop-up is displayed. Select **Reconnect** to automatically restore the connection. A confirmation pop-up will appear before the touch screen reverts to its previous mode.

CHANGING/DISCONNECTING A DEVICE

- From the menu, select **Change device**.
- Select **Disconnect**. A confirmation pop-up will appear and then you will be given the option to **Search new** or select a different device from the list of paired devices.