

**Note:** If more than 5 devices are detected, it may be necessary to use the scroll bar to see the entire list.

8. When prompted, enter the PIN code into your device. See your device operating instructions for further information.
9. Once your device is paired and connected to the system, a confirmation message will be displayed before switching to the My music, Bluetooth® view.

**Note:** Due to the duration of a Bluetooth® search, it is advised that the time-out to home screen feature is switched off before attempting to search for Bluetooth® devices. This setting can be changed within **Vehicle, Syst settings, Display set, Timeout to home screen**.

### LOSS OF CONNECTION

If a loss of connection between the vehicle and the Bluetooth® device occurs, a pop-up is displayed. Select **Reconnect** to automatically restore the connection. A confirmation pop-up will appear before the touch screen reverts to its previous mode.

### CHANGING/DISCONNECTING A DEVICE

- From the menu, select **Change device**.
- Select **Disconnect**. A confirmation pop-up will appear and then you will be given the option to **Search new** or select a different device from the list of paired devices.