

15. Seek up:

- Short press:
 - to select the next radio preset or,
 - to select the next track on chosen audio source - CD, MP3 etc.
 - when telephone is in use, press to scroll up lists of calls or phonebook entries.
- Long press:
 - to auto seek up the frequency to the next radio station.

SETTINGS

To view the settings menu, press the **SETTINGS** button (2). When Park assist is specified, the icon is changed and the button will turn Park assist on and off. The Settings menu is then accessed via the touch screen

Each of the audio/video menu screens will display a **Settings** softkey.


To adjust the audio settings:

- Touch the **+** or **-** soft keys to adjust Bass, Treble or Subwoofer levels.
- If surround sound is fitted, touch **DPLIIx**, **DTS Neo:6**, **Meridian Trifield** or select **Off** to switch surround sound off.

Note: Surround sound options are not available for certain sources where the surround sound mode is set automatically.

To adjust balance and fade:

- From the **Audio Settings** menu, select **Balance/Fade**.



SJ1080

- Touch the arrows to move the sound focal point to the desired area of the vehicle. Alternatively, drag the focal point cross hairs to a new position.